



***PROMISE ARRAY MANAGEMENT
[PAM] FOR
FASTTRAK TX2200 / TX4200
USER MANUAL***

Version 1.1

Copyright

© 2004 Promise Technology, Inc. All Rights Reserved.

Copyright by Promise Technology, Inc. (Promise Technology). No part of this manual may be reproduced or transmitted in any form without the expressed, written permission of Promise Technology.

Trademarks

Promise, and the Promise logo are registered in U.S. Patent and Trademark Office. All other product names mentioned herein may be trademarks or registered trademarks of their respective companies.

Important data protection information

You should back up all data before installing any drive controller or storage peripheral. Promise Technology is not responsible for any loss of data resulting from the use, disuse or misuse of this or any other Promise Technology product.

Notice

Although Promise Technology has attempted to ensure the accuracy of the content of this manual, it is possible that this document may contain technical inaccuracies, typographical, or other errors. Promise Technology assumes no liability for any error in this publication, and for damages, whether direct, indirect, incidental, consequential or otherwise, that may result from such error, including, but not limited to loss of data or profits.

Promise Technology provides this publication “as is” without warranty of any kind, either express or implied, including, but not limited to implied warranties of merchantability or fitness for a particular purpose.

The published information in the manual is subject to change without notice. Promise Technology reserves the right to make changes in the product design, layout, and driver revisions without notification to its users.

This version of the User Manual supersedes all previous versions.

Recommendations

The appearance in this manual of products made by other companies, including, but not limited to software, servers and disk drives, is for the purpose of illustration and explanation only. Promise Technology does not recommend, endorse, prefer or support any product made by another manufacturer.

Contents

Chapter 1: Introduction	1
PAM Components	1
How They Work Together	2
PAM Installation Options	3
Chapter 2: Installation	7
Installation Locations	7
Monitoring Utility	7
Message Server	8
Message Agent	9
Operating System Support	9
Network Requirements	9
Installation Procedure	10
PAM Installation	10
Chapter 3: Initial Setup	15
Launch PAM	15
Local Agent Log-in	17
Remote PAM Log-in	18
Create a New User	20
Create a Logical Disk	22
Setup Alert Notification	25
Add a User to the Recipient List	27
Specify Alert Notification Events	28
Chapter 4: PAM User Interface	31
Tree View	32
Local PAM	32
Remote PAM	33
Tree View and Component Specific Menus	34
Object View	35
Information View	36
Status Bar	36
Pull-down Menus	37
Toolbar	40
Popup Menus	41

Chapter 5: Monitoring and Maintenance	45
Remote PAM	45
Create a RAID Server	45
Log-in to RAID PC	47
Log-out of RAID PC	47
Disconnect from RAID Server	47
Future Connections to RAID Server	48
Message Server IP Address Change	49
Local PAM	51
User Management	52
Create a User	52
Change Password	54
Change User Rights	55
Delete a User	55
Alert Notification	56
Setup Alert Notification	56
Add a User to the Recipient List	58
Delete User from Recipient List	59
Specify Alert Notification Events	60
Controller	62
View Event Log	64
Logical Disks	65
Create a Logical Disk	65
JBOD	68
Hot Spare Drive	68
Logical Disk Critical	69
Logical Disk Offline	70
Rebuild a Logical Disk	72
Synchronize a Logical Disk	75
Expand or Convert a Logical Disk	77
Delete a Logical Disk	81
Chapter 6: RAID Concepts	83
Logical Disk Terms	83
RAID Levels	86
Choosing a RAID Level	90
Expand or Convert a Logical Disk	92
Appendix A: Partition and Format	93

Chapter 1: Introduction

Promise Array Management (PAM) is a software application designed specifically for monitoring and managing Promise Technology RAID products, such as the FastTrak TX2200 and TX4200 Serial ATA RAID Controller cards. Promise includes BIOS-based RAID management utilities with each of its products. PAM, however, runs over a local area network and makes possible RAID monitoring and management from any computer on the network and even over Internet. This allows your IT manager to watch your RAIDs and take care of them over the network.

PAM Components

There are three components to PAM. Depending on your installation, all three may be on the same workstation or work separately across your network:

Monitoring Utility – The Monitoring Utility is a Graphic User Interface (GUI) that reports on the condition of the RAID logical disk. It receives and displays reports on RAID condition and operation through the Message Server. The Monitoring Utility works on any PC with a TCP/IP network connection to your RAID.

When installed on the computer that operates the RAID, the Monitoring Utility also provides a complete set of RAID management tools.

Message Server – The Message Server is the link connecting a PC with the Monitoring Utility. Normally, the Message Server runs on a network file server. But it can also run on the PC controlling the RAID.

Message Agent – The Message Agent runs on the PC that controls the RAID, called the “RAID PC”. It directly monitors the RAID and sends messages through the Message Server to all PCs running the Monitoring Utility.

How They Work Together

The Promise Array Management (PAM) software provides an easy way to set up, monitor, modify and repair your RAID. PAM works with the Promise FastTrak TX2200 and TX4200 Serial ATA RAID Controller cards.

PAM watches the RAID and when significant events happen, or it discovers a problem, the Message Agent sends a warning to the Message Server. The Message Server passes the warning along to all PCs running the Monitoring Utility.

Warnings appear on the PC in the form of email messages and popup alerts. You can select either one or both. You can also select which events and problems PAM will report.

A major benefit of PAM is that it runs over a TCP/IP network. This enables remote monitoring of your RAIDs, including offsite monitoring over an Internet connection.

Once you become aware of a problem, go to the PC that controls the RAID, called the "RAID PC" to take corrective action. If you have more than one RAID PC on your network, PAM will indicate which one has the problem.

PAM allows only monitoring access through the network. Management access occurs only at the RAID PC.

PAM Installation Options

1. Following are some examples of ways you can incorporate PAM into your network and RAID systems.




Figure 1. LAN and Internet connections.

In the example above, there are three PCs with FastTrak cards connected to the company's LAN. The PAM Message Agent runs on each of the PCs with a FastTrak card. The PAM Message Server runs on the company's file server. The PAM Monitoring Utility runs on networked PCs and also on remote PCs connecting to the company network through the Internet. With this arrangement,

you can monitor RAID condition and activity from offsite, such as a hotel room or home office.




Figure 2. Company LAN without a File Server

In the above example, there are three PCs with FastTrak cards connected to the company's LAN, the same as before. But this network has no file server, so the PAM Message Server runs on one of the networked PCs. PAM Monitoring Utility runs on both networked PCs. If this LAN were upgraded with a suitable router and an Internet connection, you could set up offsite monitoring.




Figure 3. PCs with Internal RAID.

Promise's FastTrak card is designed to setup and control a RAID within the PC's enclosure. They have the same need of monitoring and management as an external RAID subsystem. All three PAM components run on the PC itself.



Important

This manual accompanies a special version of PAM optimized to run with the FastTrak TX2200 and TX4200.

Other versions of PAM will run reliably on the Promise RAID product with which they ship. They will also run reliably on several Promise RAID products in normal use. However, they may not perform adequately with a FastTrak TX2200 and TX4200.

Chapter 2: Installation

To install Promise Array Management (PAM) is an uncomplicated procedure, once you understand your systems and how you want to use PAM. The purpose of this Chapter is to help you plan and carry out your installation of PAM.

By way of review, PAM consists of three components:

- Monitoring Utility
- Message Server
- Message Agent

These were described in the previous chapter. Before proceeding with the installation, you must know which component goes where. If you plan to run PAM over a network, you must know the IP addresses of each computer on the network that will be involved in your RAID monitoring and management activity.

Installation Locations

In the table below are, possible locations for each of the three PAM components.

	Monitoring Utility	Message Server	Message Agent
Internet-connected PC	•		
Network PC	•	•	
Network File Server	•	•	
RAID PC	•	•	•

Monitoring Utility

The Monitoring Utility installs on any computer you will use to monitor and manage the RAIDs.

If your RAID runs without a network connection, install it on the RAID PC with the rest of the PAM components.

If your RAIDs are networked, you can install the Monitoring Utility on any computer connected to the network.

If your company has networked RAIDs and Internet access, you may choose to install the Monitoring Utility on a laptop or home-based PC for dial-in remote access.

Limit your installation to the computers of RAID users and your IT administrator. PAM features password protection to further limit access and provide security of your data.




Figure 1. Networked RAID has many installation options.

Message Server

The Message Server is required if your RAID PC connects to a network.

If you want run PAM over a network, install the Message Server on one of your networked computers including a file server, a networked PC or the RAID PC.

Only one installation of the Message Server is required for PAM to work over a network. You may install Message Server on more than one network PC or file server, but PAM's network configuration will only use one of them, thus any additional installations are useless.

Do not install the Message Server on any PC that may be disconnected from the network, such as a laptop or a computer that connects via the Internet. Not only will a disconnect cause PAM to fail, but reconnecting again may involve time-consuming network configuration.

Network configuration is discussed later in this chapter.

Message Agent

The Message Agent installs on the RAID PC, whether your RAID is networked or not. In order for PAM to monitor and manage a RAID, it must have Message Agent installed.

If you have more than one PAM-compatible RAID PC on your network, install a copy of Message Agent on each one of them.

Operating System Support

PAM is a utility designed to run on top of previously installed Promise FastTrak card. Generally, if your PC runs the FastTrak card properly, it will run PAM also.

Promise Technology recommends Windows 2000, XP Professional or Server 2003 to take full advantage of all the features of PAM. In some cases, you can run PAM on other Windows operating systems. This becomes an issue when running PAM over a network where there are PCs with different operating systems.

Network Requirements

If you plan to install PAM on a network be sure all the hosts and servers are connected and running. That is, each of the PCs, RAID's and Servers must have a working network connection before you install PAM.

In order for PAM to be configured over a network, you must know the IP (network) address of the RAID PC(s) in your system. The Message Server uses IP addresses to communicate with the Message Agent on the RAID PCs and the Monitoring Utility on the network PCs.

Installation Procedure


Before you start...

If you are installing PAM to run over a network, determine the computers and servers onto which you will install PAM. Obtain the IP addresses of all RAID PCs where PAM will be installed.


PAM Installation

With that information ready, follow these steps to install PAM on each computer or server:


1. Boot the PC/server and launch Windows.
2. If the computer is already running, exit all programs.
3. Insert FastTrak CD into your CD-ROM drive.
4. Open the CD and locate the PAM folder.
5. Inside the PAM folder, look for the PAM Setup Installer icon (right).
6. Double-click the icon to run the installer. The opening screen appears.



7. Click Next or press Enter to continue.




- When the License Agreement appears, click the “I accept” radio button to agree to the terms and continue the installation.
If you click “I do not accept,” PAM Setup will exit.




- In the Setup Type dialog box, make your choice between Typical (Recommended) and Custom installation.

Use the Custom installation to change install locations or to deselect individual components. For example, use Custom to install only the Message Server onto your network fileserver.

Click Next or press Enter to continue.



10. In the Ready to Install dialog box, click Install or press Enter to continue.



11. When the Add User Account dialog box appears, you can accept the default name or enter a new one in the Name field.

Enter your password in the Password and Confirm Password fields. A password is not required.


When you are done, click Next or press Enter to continue.



Note

If you are only installing the Message Server, this dialog box does not appear.

page 15



12. When the Install Complete dialog box appears, you have the option to:

- Create PAM shortcuts on your Desktop
- Register PAM online

Both of these options are recommended.


Click Finish or press Enter when you are done.

This completes the PAM installation. Go on to *Chapter 3: Initial Setup* on page 15.

Chapter 3: Initial Setup

After you have completed installation, you must setup your PAM Monitoring Utility to work with your RAID.

Launch PAM



To Start PAM, click on a Desktop icon or go to Start > Programs > Promise Array Management and select:


Local PAM – Use to monitor and manage the FastTrak Controller in your PC

Remote PAM – Use to monitor FastTrak Controllers over your network



Note

If you only installed the Message Server, this shortcut does not appear. The Message Server works only through network connections and has no user interface. Go to the RAID PC or a Networked PC to setup PAM.



The Monitor window (above) is the user interface for PAM. It has three views:


Tree View – Displays the elements of your RAID system. It works like Windows Explorer with hierarchical menus. You can expand individual items to see their components.


Object View – Displays icons representing the devices below the highlighted device in the Tree View.


Information View – Displays information on the item highlighted in the Tree View. This may include text boxes, list boxes, fields and buttons. It varies with the item you select in Tree View.

Local Agent Log-in

The Message Server relays data and commands between the Monitoring Utility on this computer and the Message Agent on the RAID PCLaunch Local PAM. When the PAM user interface appears:




1. Right click on the RAID Machine  icon in Tree View. Select Login from the popup menu. The Login dialog box appears.






2. In the Login dialog box, type your Username and Password, and click OK. Initially, administrator is the only user. Use the administrator's password selected during installation.


Remote PAM Log-in

Remote PAM works over your network. Therefore it requires additional steps the first time you log on. Launch Remote PAM. When the PAM user interface appears:




1. Right-click on the My Console  icon and:
 - Select New > Server from the popup menu.
 - Click the New Server  icon in the Toolbar. A RAID Server icon appears.




2. Click on the RAID Server  icon. In Information View, type in the IP address of the computer where the Message Server Software is installed. If the Message Server software is installed on the monitoring PC (the PC you are now working on), you can use the default 127.0.0.1 IP address.

- Click Submit. A list of networked RAID PCs appears as shown below.



- Right-click on the RAID Machine  icon in Tree View. Select Login from the popup menu. The Login dialog box appears.








- In the Login dialog box, type your Username and Password, and click OK. Initially, administrator is the only user. Use the administrator's password selected during installation.
If you want to log in to another user's RAID PC, obtain the User name and Password, if necessary.

Create a New User

With the Message Agent accessed, you can add a new user. The Administrator is created by default. You must create additional users manually. The administrator is created by default. You must create additional users manually.

1. Do one of the following:



- Right click on the User Management  icon and select New > User from the popup menu. A new User  icon appears.
- Or select the User Management  icon and click the Add User  button on the Toolbar.

User Configuration

User name:

Password:


Confirm Password:

Administration Rights Setting:

Creation Rights - create, delete, expand and convert arrays

Maintenance Rights - rebuild, synchronize arrays, and general settings

User Account Rights - add account, delete account, change user password

2. Right-click on the User  icon and select New > User from the popup menu (right). A new user icon appears to display the User Information View.

The User Information View displays a request for new user identification and access rights.

Rights	Definitions
Creation	Allows you to create and delete logical disks, rebuild and synchronize logical disks, and make general settings
Maintenance	Allows you to rebuild and synchronize logical disks, and make general settings
User Account	Allows user to modify his/her own rights and to create and delete other users you to add and delete user accounts and change your password


Every User has at least one of these three Rights and can change his/her own password.

The Administrator can assign more or fewer rights to other Users but cannot change their passwords.

3. Type a User name and Password in their respective fields.

Check all the appropriate boxes to set access rights. Click the Submit button when you are done.

The new user's name appears on Tree View.



Create a Logical Disk




The available RAID selection depends on the number of disk drives available.

The table below lists the RAID Levels available with FastTrak TX Series and the number of drives required.


Click the + to the left of each Channel to see the disk drive. If there is no +, the Channel does not recognize a disk drive.

The available RAID selection depends on the number of disk drives available. The table below lists the options. See page 83 for a more detailed description.

RAID Level	Name	Minimum drives	Maximum drives
0	Stripe	1	4
1	Mirror	2	2
10	Mirror + Stripe	4	4


1. In Tree View, click the + to the left of the Controller  icon to see the Logical Disk View  icon.
2. Right-click on the Logical Disk View  icon and select Create Logical Disk from the popup menu.

OR Click on the Logical Disk View  icon and look in the Information View...



...and click the Create Logical Disk button.

The Logical Disk Creation Setting box appears.




3. In the Logical Disk Creation Setting box:
 - Type in a name for your logical disk
 - Select the RAID Level from the dropdown menu
 - Set the Stripe Block Size (see below)
 - Highlight the disk drives to add to the logical disk
 - Check to enable Gigabyte Boundary, as desired (see below)

Stripe Block Size – For RAID 0 and RAID 10 logical disks, you can manually select the stripe block size, either 32, 64 or 128 KB. The size selected affects how FastTrak send and receives data blocks to and from the drives. In general, a larger block size is better when handling large data transfers (such as A/V editing and graphics) while a smaller size is better when handling email and other common server data. The default is 64KB. When in doubt, use the default value.


Gigabyte Boundary – For RAID 1 and RAID 10 logical disks. It rounds the size of the logical disk down to the nearest whole gigabyte. It allows you to install a slightly smaller (within 1 GB) replacement drive, should the need arise. To enable Gigabyte Boundary, check the box.

4. Click the Create button when you are done.



PAM reminds you that by creating this logical drive, any data on the selected disk drives will be deleted.

5. Click OK or press Enter to continue.



The new logical disk appears in Tree View and Information View (above).




Note


Before you can use your new logical disk, you must partition and format the logical disk using your PC's operating system. See page 93.

Setup Alert Notification

PAM alerts you to the problems and processes happening to your RAID through email and popup messages.

These steps describe how to setup the email function.

1. Click on the RAID Machine  icon. Information for the RAID PC appears in Information View.




Event Log Setting

Enable NT system event log

Anti-SPAM Protection: If error and/or event repeats, send new message every hrs

2. Be sure the Enable NT system event log checkbox is checked.
3. To reduce the volume of repeated messages, check the Anti-SPAM checkbox and set an acceptable time interval in hours.



E-Mail Server

Email alert on error

SMTP Server

(SMTP server name or IP. For example: smtp.mydomain.com, or 123.45.67.89)

Authentication Method

User name

Password

4. Click on the Email alert on error box, if it is not already checked.
5. In the SMTP server field, type in the SMTP address for your mail server.
6. The default is No Authentication Method. If you want an Authentication Method, in the dropdown menu choose from:
 - CRAM-MD5
 - Authorized Login
 - Plain Login
7. Type in a User Name and Password in the fields provided.
8. Click the Change button to update your configuration.

E-Mail Sender and Recipients

Email ID of Alert Sender

sysadmin@promise.com

(Input the email ID recipient for this machine, which is name<replyemail>, or "name"<email>. For example: "Administrator"<admin@mydomain.com>)

Alert Recipients Email Address


danneld@promise.com


(Input the email address like name<email> or "name"<email>. For example: "Joe Recipient"<myemail@myisp.com>)

9. Scroll down to the Email Sender and Recipients box.
10. In the Email ID of Alert Sender field, type in the email address of this computer.
11. This address will appear in the From field of the email alerts. Recipients may reply to this address, if it is valid.
12. Click the Change button to update your configuration.

Add a User to the Recipient List

After you have setup email alert notification, you must specify who shall receive the alerts.

1. Click on the RAID Machine  icon to which you wish to add an email alert message recipient.



E-Mail Sender and Recipients


Email ID of Alert Sender
sysadmin@promise.com

(Input the email ID recipient for this machine, which is name<replyemail>, or "name"<email>. For example: "Administrator"<admin@mydomain.com>)

Alert Recipients Email Address
danneld@promise.com

(Input the email address like name<email> or "name"<email>. For example: "Joe Recipient"<myemail@myisp.com>)

2. In the Alert Recipients Email Address field, type in the email address of the user who you wish to receive alerts.
3. Click the Add button when you are done. The names appear in the Current Recipients window.




Current Recipients


craigh@promise.com
michelw@promise.com
xinhalf@promise.com
samd@promise.com

4. Repeat Step 2 until all addresses have been added.


Specify Alert Notification Events

PAM can be configured to report a variety of alerts, by email, popup message or both. This section describes how to tell PAM what to report and which method to use.

1. Click on the RAID System  icon whose alert notification events you wish to modify.



2. The Event Alert Setting box has dropdown menus to help you select Alert Events quickly. To select Events, click on Options and choose Select.



3. Click on Message Type and choose message delivery by E-Mail, by Popup, by All (both) or None.

4. Click on the Severity Level and choose Error, Warning, Information, All or None.

Following is a list of Events. The term *Array* refers to a logical disk.

Information Events

Disk Plug In
 Disk Access Retry
 JBOD to Spare
 Spare to JBOD
 Controller Create Array
 Array Rebuild Started
 Array Auto Rebuild Started
 Array Rebuild Resumed
 Array Rebuild Completed
 Array Synchronization Started
 Array Synchronization Aborted
 Array Synchronization Paused
 Array Synchronization Resumed
 Array Synchronization Completed
 Array Expansion/Conversion Started
 Array Auto Expansion/Conversion Started
 Array Expansion/Conversion Completed
 Array Expansion/Conversion Resumed

Warning Events

Disk Media Error
 Disk S.M.A.R.T. Failed
 Disk ECC Error
 Disk Time Out
 Inconsistent Table Exceed Threshold
 Read Check Table Exceed Threshold
 Disk CRC Error
 Array Critical
 Controller Delete Array
 Array Rebuild Paused
 Array Expansion/Conversion Paused
 Enclosure Over Temperature
 Enclosure Fan Stop
 Enclosure 12V Error
 Enclosure 5V Error
 Enclosure 3.3V Error


Error Events

Disk Offline
 Array Media Error
 Inconsistent Table Full
 Read Check Table Full
 Array Offline
 Array Rebuild Failed
 Array Synchronization Failed
 Array Synchronization Comparison Error
 Array Expansion/Conversion Failed

5. To select an individual Event, click in the E-Mail and Popup columns to toggle between Yes and No.
6. When you are finished, click the Apply button.

Chapter 4: PAM User Interface

This chapter describes PAM's Graphic User Interface (GUI). You should understand that PAM is software running on top of the Promise RAID BIOS and other applications that came with your Promise RAID product. PAM adds a graphic user interface to make RAID management functions easier to understand and perform.




The PAM Window (above) has three views: Tree View, Object View and Information View. These views are explained on the following pages.

Tree View


Local PAM

The Tree View displays all of the elements of your RAID system. Use it to navigate to specific components.



Remote PAM

Remote PAM adds a RAID Server icon to connect with the Message Server PC in order to monitor logical disks over a network.




Normally, the Tree View is present. To close it, right-click on any object and select Hide Pane from the popup menu.

To open it again, go to View menu and select Outline.


Tree View and Component Specific Menus

In PAM, like most Windows applications, you can access the various commands and functions by opening dropdown menus and clicking on icons. Each time you click on a component in Tree View, PAM's menu bar also displays that component's dropdown menu. Below are some examples.



Rather than access the menu bar, you can right click on the icon of the component you are working with. The menu bar and popup menus for Tree View items are identical.

Object View

Object View is visible whenever the Tree View is visible. The items appearing in Object View are determined by which component you select in Tree View. In the example below, we selected a Controller  icon in Tree View.




As a result, you see the components of that Controller, in this case, the Disk View, which shows the disk drives attached to the Controller, and the Logical Disk View, which shows the logical disks created under this Controller.


This feature makes it easy to find an individual component as well as see what items are assigned to higher level components. Double-click on these items to see their components in Object View and their configuration in Information View.

Information View

Information View, like Object View, changes its content depending on which item you select in Tree View. The difference is that you use Information View to obtain data, input settings and information.




Name	RAID Mode	Size	Status
Logical Disk 1	RAID 10 (Mirror+Stripe)	73.999 GB	Functional

The example above shows what Information View displays when you click on the Logical Disk View  icon.

Status Bar

The PAM Status Bar is the same as other Windows applications. It indicates such things as the selected RAID is rebuilding, and the current user is the Administrator (below).



Normally the Status Bar is visible. To show or hide the Status Bar, go to the View menu and check or uncheck Status Bar.

Pulldown Menus

The left-most Pulldown Menu changes according to which component is selected in the Tree View.


This menu can be the Main, My Console, Server, RAID Machine, RAID System or Maintenance.

The functions of each menu are described below.

Main Menu


When no item in Tree View is selected, the left-most menu item is Main. Its only function is Exit, which quits the PAM application.

My Console Menu

When the My Console  icon is selected, the My Console menu appears. Its functions include:

- Create a new Server
- Screen refresh
- Rename the My Console icon
- Exit PAM


Server Menu

The Server menu appears when the RAID Server  icon is selected.

This menu applies only to Remote PAM. Its functions include:


- Modify the connection
- Delete the connection
- Connect
- Disconnect
- Screen refresh
- Rename the Server icon
- Exit PAM

RAID Machine Menu

When the RAID Machine  icon is selected, the RAID Machine menu appears. Its functions include:


- Login
- Logout
- Screen refresh
- Rename the RAID Machine icon
- Exit PAM

RAID System Menu


The RAID System menu appears with the RAID System  icon is selected. Its functions include:

- Screen refresh
- Rename the RAID System icon
- Exit PAM

Maintenance Menu

When the Controller  icon is selected, the Maintenance menu displays Controller functions:

- Read Events in the Event Viewer
- Clear Events from the Event Viewer
- Toggle the Beeper on and off
- Refresh the screen
- Rename the Controller icon
- Exit PAM

When the Logical Disk View  icon is selected, the Maintenance menu displays Controller functions:

- Create a logical disk
- Refresh the screen
- Rename the Logical Disk icon

View Menu

The View menu is always the same. It displays or hides three items:

- Toolbar
- Status Bar
- Outline (Tree View)

Check to display or uncheck to hide each one as you prefer.

Connection Menu

The Connection menu is always the same. It deals with server connections. Use it to:

- Create a new Message Server
- Connect to a RAID Server
- Disconnect from a RAID server

Preference Menu

The Preference menu is always the same. It allows you to start PAM automatically when your PC boots.

- Run on Startup

Check to enable or uncheck to disable this feature.

If you are using PAM for remote monitoring, running PAM automatically is a good idea. This way, your PC will be connected to the RAID and you will receive all the alerts messages you have specified.

Help Menu

The Help menu is always the same. Under Help, PAM has:

- Full online Help file
- Auto Demo display
- About page with PAM information

Toolbar


The Toolbar is a series of buttons that are shortcuts to performing specific tasks. You will never see all buttons active as in the example below.




They become active when you click on specific system components in Tree View. Only the tool buttons pertaining to that component are active.

Most of these functions require User Account Rights. These are specified when a User is added or modified. Following is a description of the Toolbar buttons:




New Server. Available when you select the MyConsole  icon in Remote PAM. Creates a new Message Server.




Connect. Available when you select the Message Server  icon in Remote PAM. Initiates a connection with the RAID Server.




Disconnect. Available when you select a Message Server  icon. Disconnects from the RAID Server. Used when you want to shut down a RAID server for repair.



Delete User. Available when you select a User  icon. Deletes the user from monitoring and alert access.



New User. Available when you select the User Management  icon.



About. Brings up the information about this version of PAM.



Help. Always available. Brings up the Online Help.

Popup Menus


In addition to the commands in the dropdown menus, there is a corresponding set of commands you can access via popup menus.

In a popup menu, you can use any of the commands that are in black.

You will notice that some functions are grayed out, meaning that you cannot use them.

Many functions require that you have User Account Rights to perform them.

MyConsole Icon

Right-click on the MyConsole  icon to access the following commands:

- New Server (Remote PAM)
- Screen refresh

Message Server Icon

Right-click on the Message Server  icon to access the following commands:


- Modify the connection
- Delete the connection
- Connect
- Disconnect
- Screen refresh

RAID Machine Icon

Right-click on the RAID Machine  icon to access the following commands:


- Login
- Logout
- Screen refresh
- Rename the RAID Machine icon

RAID System Icon

The RAID System  icon represents the FastTrak TXII Family of RAID Controller cards. There is one command for this item:


- Screen refresh

Controller Icon

Right-click on the Controller  icon to access the following commands:



- Read Events in the Event Viewer
- Clear Events from the Event Viewer
- Toggle the Beeper on and off
- Refresh the screen

Disk View Icon

The Disk View icon  represents an individual channel on the FastTrak Controller card. There is one command for this item.

- Refresh the screen

Disk Icon

Right-click on the Disk  icon of an unassigned drive or the Disk  icon of an assigned drive to access the following command:

- Refresh the screen

Logical Disk View Icon

Right-click on the Logical Disk View  icon to see all of the logical disks on this controller.


- Create a logical disk
- Refresh the screen

Logical Disk Icon

Right-click on the Logical Disk  icon to access the following commands:


- Synchronize this logical disk
- Delete this logical disk
- Pause synchronization/rebuild/expand/convert
- Continue synchronization/rebuild/expand/convert
- Refresh the screen
- Rename the Logical Disk icon

User Management Icon

Right-click on the User Management  icon to access the following commands:

- Create a New User
- Refresh the screen

User Icon

Right-click the User icon  to access the following commands:

- Delete this User
- Refresh the screen

Chapter 5: Monitoring and Maintenance


This chapter describes using PAM to monitor and manage your RAID system. The chapter is divided into sections for major PAM components as follows:



- Remote PAM (below)
- Local PAM (page 51)
- User Management (page 52)
- Alert Notification (page 56)
- Controller (page 62)
- Event Log (page 64)
- Logical Disks (Arrays) (page 65)

Remote PAM


Create a RAID Server

Remote PAM works over your network. Therefore it requires additional steps the first time you log on. Launch Remote PAM. When the PAM user interface appears:





1. Right-click on the My Console  icon and:
 - Select New > Server from the popup menu.
 - Click the New Server  icon in the Toolbar.

A RAID Server icon appears.




The screenshot shows a 'RAID System Configuration' dialog box. It contains three input fields: 'Label' with the value 'RAIDSERVER1', 'Server Name' with the value 'New Server1', and 'IP Address' with the values '192', '168', '1', and '136' separated by dots. At the bottom, there are two buttons: 'Reset' and 'Submit'. A mouse cursor is pointing at the 'Submit' button.

2. Click on the RAID Server  icon. In Information View, type in the IP address of the computer where the Message Server Software is installed. If the Message Server software is installed on the monitoring PC (the PC you are now working on), you can use the default 127.0.0.1 IP address.
3. Click Submit. A list of networked RAID PCs appears as shown below.



Log-in to RAID PC


1. Right-click on the RAID Machine  icon in Tree View. Select Login from the popup menu. The Login dialog box appears.



2. In the Login dialog box, type your Username and Password, and click OK. Initially, administrator is the only user. Use the administrator's password selected during installation.
If you want to log in to another user's RAID PC, obtain the User name and Password, if necessary.

Log-out of RAID PC




You can log out of one RAID PC while remaining connected to others on the network.

Right-click on the RAID Machine  icon of the PC you want to disconnect and select Logout from the popup menu.


Disconnect from RAID Server


Logout of the RAID Server effectively logs you out of all RAID PCs using that network connection.

To disconnect from the network:




- Right-click on a RAID Server  icon and select Disconnect from the popup menu.
- Or right-click on the RAID Server  icon and click the Disconnect  icon in the Toolbar.

Future Connections to RAID Server


The RAID Server remains under the MyConsole  icon until deleted. It continues to work as long as the IP address is correct.



To make a connection with an existing RAID Server:


- Right-click on a RAID Server  icon and select Connect from the popup menu.
- Or right-click on the RAID Server  icon and click the Connect  icon in the Toolbar.

The Login list of networked RAID PCs appears as before.






Message Server IP Address Change

If the IP address changes for the computer where the Message Server software is installed, an existing RAID Server with the old address will no longer work.




1. Right-click on a RAID Server  icon and select Delete from the popup menu.
2. Click OK in the confirmation dialog box.




3. Right-click on the My Console  icon and:
 - Select New > Server from the popup menu.
 - Click the New Server  icon in the Toolbar.

A RAID Server icon appears..




4. Click on the RAID Server icon. In Information View, type in the IP address of the computer where the Message Server Software is installed. If the Message Server software is installed on the monitoring PC (the PC you are now working on), you can use the default 127.0.0.1 IP address.
5. Click Submit. A list of networked RAID PCs appears as shown below.




Local PAM

Log-in


Launch Local PAM. When the PAM user interface appears:

1. Right click on the RAID Machine  icon in Tree View. Select Login from the popup menu. The Login dialog box appears.



2. In the Login dialog box, type your Username and Password, and click OK. Initially, administrator is the only user. Use the administrator's password selected during installation.

Log-out


To log-out of a Local PAM, right-click on the RAID Machine  icon and select Logout from the popup menu.





User Management

Create a User

With the Message Agent accessed, you can add a new user. The Administrator is created by default. You must create additional users manually. The administrator is created by default. You must create additional users manually.



1. Do one of the following:



- Right click on the User Management  icon and select New > User from the popup menu. A new User  icon appears.
- Or select the User Management  icon and click the Add User  button on the Toolbar.

A 'User Configuration' dialog box. It contains the following fields and options:

- User name:
- Password:
- Confirm Password:
- Administration Rights Setting:
 - Creation Rights - create, delete, expand and convert arrays
 - Maintenance Rights - rebuild, synchronize arrays, and general settings
 - User Account Rights - add account, delete account, change user password
- Buttons: and

2. Right-click on the User  icon and select New > User from the popup menu (right). A new user icon  appears to display the User Information View..

The User Information View displays a request for new user identification and access rights.

Rights	Definitions
Creation	Allows you to create and delete logical disks, rebuild and synchronize logical disks, and make general settings
Maintenance	Allows you to rebuild and synchronize logical disks, and make general settings
User Account	Allows user to modify his/her own rights and to create and delete other users you to add and delete user accounts and change your password


Every User has at least one of these three Rights and can change his/her own password.

The Administrator can assign more or fewer rights to other Users but cannot change their passwords.

3. Type a User name and Password in their respective fields.

Check all the appropriate boxes to set access rights. Click the ComSubmit button when you are done.


The new user's name appears on Tree View.




Change Password

Every User can change his/her own password.

The Administrator cannot change other Users' passwords.

1. Log-in to PAM under the User Name whose Password you want to change.
2. Click on the  icon of the User whose Password you want to change.



User Configuration

User name: Samuel Adams

Password: *****

Confirm Password: *****

Administration Rights Setting:


- Creation Rights - create, delete, expand and convert arrays
- Maintenance Rights - rebuild, synchronize arrays, and general settings
- User Account Rights - add account, delete account, change user password


Submit Reset

3. In Information View, type in a new Password in the two Password fields.
4. Click the Submit button when you are done.

Change User Rights


The Administrator can change any User's Rights. Other Users cannot change their Rights.

1. Log into PAM as the Administrator.
2. Click on the  icon of the User whose Rights you want to change.



3. In Information View, check or uncheck Rights options as desired (above).
4. Click the Submit button when you are done.



Delete a User

1. Log into PAM as the Administrator.
2. Right-click on the  icon of the User you wish to delete and select Delete from the popup menu.
3. In the confirmation dialog box, click OK.



Note

PAM will always keep one user account with access rights, typically the Administrator. This action protects you from being locked out of the system.


Another way to delete a User: Select the User's  icon in Tree View then click the Delete User button  in the Toolbar.


Alert Notification

Setup Alert Notification

PAM alerts you to the problems and processes happening to your RAID through email and popup messages.

These steps describe how to setup the email function.

1. Click on the RAID Machine  icon. Information for the RAID PC appears in Information View.




Event Log Setting

Enable NT system event log

Anti-SPAM Protection: If error and/or event repeats, send new message every hrs

2. Be sure the Enable NT system event log checkbox is checked.
3. To reduce the volume of repeated messages, check the Anti-SPAM checkbox and set an acceptable time interval in hours.



E-Mail Server

Email alert on error

SMTP Server

(SMTP server name or IP. For example: smtp.mydomain.com, or 123.45.67.89)

Authentication Method

User name

Password

4. Click on the Email alert on error box, if it is not already checked.
5. In the SMTP server field, type in the SMTP address for your mail server.
6. The default is No Authentication Method. If you want an Authentication Method, in the dropdown menu choose from:
 - CRAM-MD5
 - Authorized Login
 - Plain Login
7. Type in a User Name and Password in the fields provided.
8. Click the Change button to update your configuration.

E-Mail Sender and Recipients

Email ID of Alert Sender

(Input the email ID recipient for this machine, which is name<replyemail>, or "name"<email>. For example: "Administrator"<admin@mydomain.com>)


Alert Recipients Email Address


(Input the email address like name<email> or "name"<email>. For example: "Joe Recipient"<myemail@myisp.com>)

9. Scroll down to the Email Sender and Recipients box.
10. In the Email ID of Alert Sender field, type in the email address of this computer.
11. This address will appear in the From field of the email alerts. Recipients may reply to this address, if it is valid.
12. Click the Change button to update your configuration.

Add a User to the Recipient List


After you have setup email alert notification, you must specify who shall receive the alerts.

1. Click on the RAID Machine  icon to which you wish to add an email alert message recipient.



The screenshot shows a window titled "E-Mail Sender and Recipients". It contains two input fields and two buttons. The first input field is labeled "Email ID of Alert Sender" and contains the text "sysadmin@promise.com". To its right is a "Change" button. Below this field is a note: "(Input the email ID recipient for this machine, which is name<replyemail>, or "name"<email>. For example: "Administrator"<admin@mydomain.com>)". The second input field is labeled "Alert Recipients Email Address" and contains the text "danneld@promise.com". To its right is an "Add" button. Below this field is a note: "(Input the email address like name<email> or "name"<email>. For example: "Joe Recipient"<myemail@myisp.com>)".

2. In the Alert Recipients Email Address field, type in the email address of the user who you wish to receive alerts.
3. Click the Add button when you are done. The names appear in the Current Recipients window.




The screenshot shows a window titled "Current Recipients". It contains a list of email addresses: "craigh@promise.com", "michelw@promise.com", "xinhaif@promise.com", and "samd@promise.com". To the right of the list is a "Remove" button.


4. Repeat Step 2 until all addresses have been added.

Delete User from Recipient List

To remove a recipient from the Email Address List, do the following:

1. Click on the RAID Machine  icon from which you wish to delete an email alert message recipient.


The Current Recipients window appears in the Information View.




2. Select the recipient you wish to delete
3. Click the Remove button or press the Delete key to remove the address from the list.


Specify Alert Notification Events

PAM can be configured to report a variety of alerts, by email, popup message or both. This section describes how to tell PAM what to report and which method to use.

1. Click on the RAID System  icon whose alert notification events you wish to modify.



2. The Event Alert Setting box has dropdown menus to help you select Alert Events quickly. To select Events, click on Options and choose Select.



3. Click on Message Type and choose message delivery by E-Mail, by Popup, by All (both) or None.

- Click on the Severity Level and choose Error, Warning, Information, All or None.

Following is a list of Events. The term *Array* refers to a logical disk.

Information Events

Disk Plug In
 Disk Access Retry
 JBOD to Spare
 Spare to JBOD
 Controller Create Array
 Array Rebuild Started
 Array Auto Rebuild Started
 Array Rebuild Resumed
 Array Rebuild Completed
 Array Synchronization Started
 Array Synchronization Aborted
 Array Synchronization Paused
 Array Synchronization Resumed
 Array Synchronization Completed
 Array Expansion/Conversion Started
 Array Auto Expansion/Conversion Started
 Array Expansion/Conversion Completed
 Array Expansion/Conversion Resumed

Warning Events

Disk Media Error
 Disk S.M.A.R.T. Failed
 Disk ECC Error
 Disk Time Out
 Inconsistent Table Exceed Threshold
 Read Check Table Exceed Threshold
 Disk CRC Error
 Array Critical
 Controller Delete Array
 Array Rebuild Paused
 Array Expansion/Conversion Paused
 Enclosure Over Temperature
 Enclosure Fan Stop
 Enclosure 12V Error
 Enclosure 5V Error
 Enclosure 3.3V Error

Error Events


Disk Offline
 Array Media Error
 Inconsistent Table Full
 Read Check Table Full
 Array Offline
 Array Rebuild Failed
 Array Synchronization Failed
 Array Synchronization Comparison Error
 Array Expansion/Conversion Failed

- To select an individual Event, click in the E-Mail and Popup columns to toggle between Yes and No.
- When you are finished, click the Apply button.

Controller

Options

The Controller has system information and settings several important features.

Click on the Controller  icon in Tree View to see the Options in Information View. To return to the previous settings, click Reset. To Apply the changes you have made, click Submit..

System Information	
Hardware Type	FastTrak TX4200
Driver Version	1.00.210.26
ASIC Version	PDC20519 Rev 2
BIOS Version	2.00.0.20

Disk Parameters	
<input checked="" type="checkbox"/> Enable S.M.A.R.T Check	
<input type="checkbox"/> Disable Hard Disk Write Cache	
<input checked="" type="checkbox"/> Enable NCQ/TCQ	

Maintenance Setting	
<input type="checkbox"/> Disable Hot Spare/Auto Rebuild	
Maintenance Rate	Low <input type="range" value="50"/> High

Maintenance Error Handling Policy - On Disk Error		
<input type="radio"/> Abort	<input type="radio"/> Skip	<input checked="" type="radio"/> Fix

System Information

This describes the Controller type, in this case a FastTrak TX4200, and the FastTrak driver version. This information may be helpful when upgrading your FastTrak or troubleshooting the PC.

Disk Parameters

Check the respective boxes to enable these features:

SMART Check – SMART, an acronym for Self-Monitoring Analysis and Reporting Technology, is a feature of the disk drive software. It monitors the

internal performance of the drive and reports to the PC when it finds a potential failure. SMART warns you of a developing drive failure so you can replace the drive before it actually fails.

Disable Hard Disk Write Cache – Disables the Write Cache on the hard disk drives. This action will reduce performance.

Enable NCQ/TCQ – Enables the FastTrak controller to work with the NCQ or TCQ features of disk drives.

Native Command Queuing (NCQ) is a feature of SATA 1.0 Extensions compliant disk drives that allows them to reorder up to 32 commands they receive for optimal read/write performance.

Tagged Command Queuing (TCQ) is the capability to reorder up to 128 read/write commands based on position of data under read/write heads, to increase read/write performance. A SCSI feature.

Maintenance Setting

Check the respective boxes to enable these features:

Disable Hot Spare/Auto Rebuild – Disables automatic rebuilding using a hot spare drive or a newly installed replacement drive. This feature requires a FastTrak TX4200 controller, a RAID 1 (mirrored) logical disk and a spare disk drive of adequate capacity. With this option checked, you must initiate rebuilding manually.

Maintenance Rate – Allocates system resources between rebuilding the Following is a list of Events. The term *Array* refers to a logical disk and responding to read/write commands from the computer system.

A *High* setting assigns most of the system resources to a rebuild or synchronization of the Following is a list of Events. The term *Array* refers to a logical disk.. The process will finished sooner but read/write requests are handled slower.

A *Low* setting assigns most of the system resources to handling read/write requests. Read/write requests are handled at nearly normal speed while the rebuild or synchronization takes longer.

See page 72 for more information on the rebuilding process.

Maintenance Error Handling Policy – On Disk Error


When the FastTrak controller discovers a disk error during synchronization, this setting directs the controller to abort synchronization, skip over the disk error or repair the disk error.


1. Make the changes you want to the Controller settings.
2. When you are finished, click the Submit button.

View Event Log

The Controller's Memory Buffer records all the events that happen on the RAID, classified as Errors, Warnings and Information.

These are very useful for diagnosing and solving problems on your system.

To see the Event Log, right-click on the Controller icon  in Tree View and select Read Events from the popup menu.



In the Event Viewer, you can view the events, make a permanent record by saving them to a file, and clear the events from the Viewer.

You can also clear the events using the popup menu in Tree View.

Note that the collecting and reporting of these Events is independent from the Alert Notification preferences set for the RAID System.

Logical Disks

- Create a Logical Disk (below)
- JBOD (page 68)
- Hot Spare Drive (page 68)
- Logical Disk Critical (page 69)
- Logical Disk Offline (page 70)
- Rebuild a Logical Disk (page 72)
- Synchronize a Logical Disk (page 75)
- Expand or Convert a Logical Disk (page 77)
- Delete a Logical Disk (page 81)

Create a Logical Disk

The available RAID selection depends on the number of disk drives available.

The table below lists the RAID Levels available with FastTrak Serial ATA RAID Controller and the number of drives required.



Click the + to the left of each Channel to see the disk drive. If there is no +, the Channel does not recognize a disk drive.

The available RAID selection depends on the number of disk drives available. The table below lists the options. See page 83 for a more detailed description.

RAID Level	Name	Minimum drives	Maximum drives
0	Stripe	1	4
1	Mirror	2	2
10	Mirror + Stripe	4	4


Although JBOD is technically not a RAID level, the JBOD option is included in the RAID Level menu on the Logical Disk Creation Setting.

JBODs are single drives only. See page 68 for more information.

1. In Tree View, click the + to the left of the Controller  icon to see the Logical Disk View  icon.


2. Right-click on the Logical Disk View  icon and select Create Logical Disk from the popup menu.

OR Click on the Logical Disk View  icon and look in the Information View...



...and click the Create Logical Disk button.

The Logical Disk Creation Setting box appears.




3. In the Logical Disk Creation Setting box:
 - Type in a name for your logical disk
 - Select the RAID Level from the dropdown menu
 - Set the Stripe Block Size (see below)
 - Highlight the disk drives to add to the logical disk
 - Check to enable Gigabyte Boundary, as desired (see below)

Stripe Block Size – For RAID 0 and RAID 10 logical disks, you can manually select the stripe block size, either 32, 64 or 128 KB. The size selected affects how FastTrak sends and receives data blocks to and from the drives. In general, a larger block size is better when handling large data transfers (such as A/V editing and graphics) while a smaller size is better when handling email and other common server data. The default is 64KB. When in doubt, use the default value.


Gigabyte Boundary – For RAID 1 and RAID 10 logical disks. It rounds the size of the logical disk down to the nearest whole gigabyte. It allows you to install a slightly smaller (within 1 GB) replacement drive, should the need arise. To enable Gigabyte Boundary, check the box.

4. Click the Create button when you are done.



PAM reminds you that by creating this logical drive, any data on the selected disk drives will be deleted.

5. Click OK or press Enter to continue.



The new logical disk appears in Tree View and Information View (above).





Note

Before you can use your new logical disk, you must partition and format the logical disk using your PC's operating system. See page 93.

JBOD

JBOD stands for “Just a Bunch of Disks” and refers to a method of disk drive management where each drive functions separately. This is the opposite of a RAID, where multiple disk drives function as one logical drive.

Create a JBOD the same way as a logical drive, except that you select JBOD rather than a RAID Level, and you assign only one disk drive at a time to JBOD.



Note that the JBOD drives are shown with the same icon as logical disks in the PAM user interface.

Hot Spare Drive

This arrangement applies to the FastTrak TX4200. For automatic rebuilds of a Mirrored (RAID 1) logical disk, attach a spare drive to the TX4200 card. FastTrak will use the unassigned drive as a hot spare, providing it:

- Is not assigned to an logical disk
- Is designated Spare (not JBOD)
- Is the same size or larger than the drives in the logical disk

If the logical disk suffers a disk drive failure, it goes Critical. FastTrak will replace the failed drive with the hot spare rebuild the logical disk automatically. This action is performed in the background under all supported operating systems. At a later time, you can power down the system and replace failed drive. If the new drive meets the requirements, it then becomes the hot spare.

FastTrak TX2200 does not support a hot spare drive because has only two channels. TX4200 supports a hot spare drive only with a RAID 1 (mirrored) logical disk. It cannot support a hot spare if you have a RAID 10 (mirror/striped) logical disk.

For more information on rebuilding logical disks, see Rebuild a Logical Disk on page 72.





Important

Be sure the Disable Hot Spare/Auto Rebuild checkbox is NOT checked. See page 62.


Logical Disk Critical

When a disk drive fails on a fault-tolerant logical disk (RAID 1 and 10) for any reason, the logical disk goes Critical. The logical disk can still read and write data but fault tolerance has been lost.

An Logical Disk Critical  icon displays in Tree View. Your first action is to identify which disk drive has failed.

1. Click on the Logical Disk Critical  icon to expand it.
2. Observe the Disk Mapping in the Information View. Look for the disk drive that was part of this logical disk but is now missing.

Case 1: With Hot Spare Drive




In the example above, there are two disk drives, in Channels 1 and 3, assigned to a RAID 1 logical disk.

The disk drive on Channel 1 does not appear. This is the failed drive.

In this case, the Hot Spare option is enabled (see page 62) and a spare disk drive is available, in Channel 4. The logical disk will begin to Rebuild automatically.

When rebuilding is finished and the logical drive returns to Functional status, power down the system and replace the failed disk drive.

Case 2: Without Hot Spare Drive



In the example above, there are four disk drives, in Channels 1, 2, 3 and 4, assigned to a RAID 10 logical disk.

The disk drive on Channel 3 does not appear. This is the failed drive.


In this case, there is no Hot Spare drive because all the FastTrak controller channels are taken by assigned disk drives.


You must power down your system and replace the failed disk drive. After you replace the failed drive, go on to Rebuild a Logical Disk on page 72.


Logical Disk Offline

When a disk drive fails on a non-fault-tolerant logical disk (RAID 0) for any reason, the logical disk goes Offline. The logical disk cannot read or write data. All of the data on the logical disk will be lost unless the failed drive is restored to operation.

A fault-tolerant logical disk (RAID 1 or 10) will go Offline if two disk drives fail.

An Logical Disk Offline  icon displays in Tree View. Your first action is to identify which disk drive has failed, the same as with Critical logical disk, above,

1. Click on the Logical Disk Offline  icon to expand it.
2. Observe the Disk Mapping in the Information View. Look for the disk drive that was part of this logical disk but is now missing.



In the example above, there are two disk drives, in Channels 1 and 2, assigned to a RAID 0 logical disk, which is non-fault-tolerant.


The disk drive on Channel 1 does not appear. This is the failed drive.


In this case, a Hot Spare drive cannot be used because this is a RAID 0 logical disk. There is no Rebuild function for a non-fault-tolerant logical disk. There are two actions you can take that could possibly restore your logical disk:

- Power down your system and check the connections to the failed disk.
- Run the drive manufacturer's diagnostic program in an effort to restore the drive to operation.

Rebuild a Logical Disk

To Rebuild is to restore redundancy to a RAID 1 or 10 logical disk after one of its drives has failed. Unlike Synchronization, a Rebuild is a repair operation.

When a drive fails for any reason, the logical disk goes Critical. A Logical Disk Critical  icon displays in Tree View.



Automatic Rebuild

Normally, the rebuild process begins automatically when you replace the faulty disk drive. The logical disk recognizes the new or spare drive and begins the process a few moments later.

If your logical disk has a Hot Spare drive (see page 68), the rebuild begins without waiting for a replacement drive. Be sure to replace the faulty drive as soon as possible.

During the Rebuild process, the logical is still available to read and write data but it may run noticeably slower.


When the rebuild is successfully completed, the logical disk will return to Functional status.

Manual Rebuild


After you replace a failed disk drive, the replacement drive must be rebuilt in order to restore the logical disk.

To initiate an logical disk Rebuild manually:


1. In Tree View, select the Logical Disk  icon of the logical disk you want to rebuild.



2. In Information View, click on the Start button inside the Rebuild Wizard box.





3. In the Rebuild Wizard, select the drive to be rebuilt (the replacement drive) and click Next.



To confirm the rebuild choice, click Finish.

Tree View and Information View display the progress (below).




During the Rebuild process, the logical disk will be available for use but it may run noticeably slower. Rebuild priority is adjustable in the Controller settings, see page 62.

If the popup messages are enabled, one will notify you when the Rebuild is successfully completed. The logical disk will return to Functional status.

Stop, Pause, Continue

Promise recommends that you let your Rebuild run to completion. However, if you need to pause the process:

1. Right-click on the icon  of the Logical Disk that is rebuilding and select Pause from the popup menu.
2. To continue, right-click on the same icon again and select Continue from the popup menu.


Synchronize a Logical Disk

Promise uses the term *Synchronization* to mean an automated process of checking and correcting data and parity. Unlike a Rebuild, Synchronization is a maintenance operation.

Synchronization applies to RAIDs 1 and 10. It takes place when an logical disk is first created and then, optionally, on a regularly scheduled basis to maintain content integrity.

Scheduled Synchronization

Schedule a time for synchronization when the RAID is least busy reading and writing data. The early morning hours are often a convenient time.



Array Synchronization Schedule


Enabled Change

By Day start at 2:00 AM

By Week every Wednesday

By Month on the 1 st


To enable and set a scheduled Synchronization:

1. In Tree View, select the RAID Machine  icon. In Information View, scroll down to the bottom.
2. Check the Enabled box.
3. Click on the radio button beside the time interval (by day, week or month) you want.
4. Based on the time interval you selected, enter the clock time, day of the week or day of the month for the synchronization process to begin.
5. When you are done, click the Change button.


The Synchronization Schedule is set. If the Schedule is disabled, it will remember its current settings.

On Demand Synchronization

In addition to schedule Synchronization, you can direct FastTrak to begin the Synchronization process immediately. To access this feature:

1. Right-click on the Logical Disk  icon and select Synchronize from the popup menu.
2. Click OK to the confirmation message.

Information View displays the progress (below).




During the Synchronization, the logical disk will be available for use but it may run noticeably slower. Synchronization priority is adjustable in the Controller settings, see page 62.

If the popup messages are enabled, one will notify you when the Synchronization is successfully completed. The logical disk will return to Functional status.

Stop, Pause, Continue


Promise recommends that you let your Synchronization run to completion. However, if you need to pause the process:


1. Right-click on the icon  of the Logical Disk that is synchronizing and select Pause from the popup menu.
2. To continue, right-click on the same icon again and select Continue from the popup menu.

Expand or Convert a Logical Disk


To expand a logical disk means to add more disk drives to it. To convert, (sometimes called “migrate”) a logical disk means to change its RAID Level. Both of these operations are possible while the existing logical drive remains online and available for data read/write functions.

PAM has a RAIDsmart Wizard that makes it easy to expand and convert existing logical drives. For a list of possible Expansion and Conversion options, see page 92.


1. Click on the icon  of the logical disk you want to expand or convert.



2. In the Information View, click on the RAIDsmartWizard Start button. The RAIDsmart opening screen displays.




3. Click Next in the RAIDsmart Wizard opening screen. The Configuration screen displays.



4. The Configuration screen offers the choice of Wizard or Manual Mode.
 - Wizard selects the additional disk drives. You must select the target RAID Level from the dropdown menu at the left.
 - Manual lets you select the disk drives and target RAID level in subsequent steps.


Make your choice and click Next to continue.

If you chose Wizard Mode, skip to the Finish screen below.




5. Click on the available free disk drives to add them to your logical disk, then click Next to continue.

Note that the number of disk drives you select here will affect the RAID Level choices in the next screen.





- Click on the target RAID level you want for your logical disk, then click Next to continue.


The Finish screen appears.



- Review the proposed Expansion or Conversion in the Finish screen. Click Finish to accept the settings and begin the Expansion or Conversion process.




The example above shows the Expansion of a single-drive to a two-drive RAID 0 logical disk. When the Status changes to Functional, the Expansion is complete.



The example above shows the Conversion of a two-drive RAID 0 to a four-drive RAID 10 logical disk. When the Status changes to Functional, the Conversion is complete.


Stop, Pause, Continue

Promise recommends that you let your Expansion or Conversion run to completion. However, if you need to pause the process:

1. Right-click on the icon  of the Logical Disk that is expanding/converting and select Pause from the popup menu.
2. To continue, right-click on the same icon again and select Continue from the popup menu.

Delete a Logical Disk

To delete a logical disk:

1. Right-click on the icon  of the Logical Disk you want to delete.
2. Select Delete from the popup menu.
3. Click OK in the confirmation dialog box.

Chapter 6: RAID Concepts

- Disk Logical Disk Terms (page 83)
 - RAID Levels (page 86)
 - Choosing a RAID Level (page 90)
 - Expand or Convert a Logical Disk (page 92)
-

Logical Disk Terms

Logical Disk

A *logical disk* (sometimes known as an *array*) is formed from a group of two or more disk drives that appear to the PC's operating system as a single drive. The FastTrak Serial ATA RAID Controller provides the organization and management for your disk drives so they can work together in this way. FastTrak allows you to create a single-drive RAID 0 logical disk but such a logical disk has no advantage over any other single disk drive.

Member

The individual disk drives in an logical disk are called *members*. Each member of a specific logical disk has coded in its *reserve sector* the configuration information that identifies the drive as a member of a specific logical disk. All disk members in a logical disk are recognized as a single physical drive to the PC's operating system.

Types

FastTrak logical disks conform to the Redundant Array of Independent Disks technology, or *RAID*. RAIDs are used to:

- Increase throughput performance
- Provide fault tolerance protection

RAID 0 Stripe increases performance by working multiple disk drives in parallel or simultaneously. RAID 1 Mirror provides fault tolerance by providing a full copy of the data on two separate disk drives. RAID 10 Mirror/Stripe (TX4200 only) combines RAID 0 and RAID 1 techniques to provide both increased performance and fault tolerance.

The chart below summarizes the features and advantages of each RAID level that you can achieve with the FastTrak Controller card.

RAID Level	Performance	Fault Tolerance	Capacity	No. of Drives
RAID 0 Striping	Highest	No	No. Drives x Smallest Size	1 to 4
RAID 1 Mirroring	Normal	Yes	Smallest Size Drive	2 only
RAID 10 Mirror/Stripe	High	Yes	2X Smallest Size Drive	4 only

Stripe Block Size

The size selected (32, 64, 128 KB) affects how FastTrak sends data blocks to and receives them from the drives. You must perform your own testing to determine how the data block size affects your particular use of the logical disk. In general, a larger block size is better when handling large data transfers (such as in A/V editing or graphics) while a smaller block size is better when handling e-mail and other common server data. The default is 64 KB.

Gigabyte Rounding

The Gigabyte Rounding feature is designed for mirrored logical disk (RAID 1 or RAID 10) that makes replacing a disk drive easier. When an logical disk goes Critical because a disk drive has failed, you must replace the failed drive with one that is the same size or larger. However, the Gigabyte Rounding feature permits the installation of a replacement drive that is slightly smaller (within 1 gigabyte) than the remaining working drive.

This can be helpful in the event that a drive fails and an exact replacement model is no longer available. Without this feature enabled, FastTrak TX2200 or TX4200 will NOT permit the use of a replacement drive that is slightly smaller than the remaining working drive.

For the Gigabyte Rounding feature to work, the Gigabyte Rounding feature must be set to ON when the original mirrored logical disk is created. When enabled, the Gigabyte Rounding feature rounds the drive capacity of both drives to the common whole GB drive size. For example, with the Gigabyte Rounding feature enabled, the remaining working drive can be 80.5 GB and the replacement drive can be 80.3, since both are rounded down to 80GB.

This permits the smaller drive to be used. Please note that users will lose a small amount of available storage capacity from both drives in order to arrive at a common drive size.



Note

Gigabyte Rounding is automatically disabled when you create a mirrored logical disk (RAID 1) from an existing drive (versus using two brand new drives). This protects the existing drive's partition table in order to maintain data integrity.

How FastTrak Orders Logical Disks

During startup, the logical disks on the FastTrak Serial ATA Controller card are recognized in this order:

1. The logical disk set to bootable in the FastBuild Setup.
2. The logical disk number (i.e. Logical disk 0, Logical disk 1...). This would be involved in determining which drive letters will be assigned to each logical disk.

How FastTrak Saves Logical Disk Information

All logical disk data is saved into the *reserve sector* on each disk drive in the logical disk. The FastTrak controller can recognize disk drive members even if they are moved between different FastTrak card connectors or they belong to a logical disk created with a different Promise RAID controller.

RAID Levels


Stripe (RAID 0)

Reads and writes sectors of data interleaved between multiple drives. When any disk member fails, it affects the entire logical disk. Performance is better than a single drive since the workload is balanced between the logical disk members.

This logical disk type is for high performance systems. Identical drives are recommended for performance as well as data storage efficiency. The logical disk data capacity is equal to the number of drive members times the smallest member capacity. For example, one 100 GB and three 120 GB drives will form a 400 GB (4 x 100 GB) logical disk.

Stripe Size – For RAID 0 logical disks you can manually select the stripe block size of 32, 64, 128 MB. The default is 64 KB.


The size selected affects how FastTrak sends data blocks to and receives them from the drives. You must perform your own testing to determine how the data block size affects your particular use of the logical disk. In general, a larger block size is better when handling large data transfers (such as in A/V editing or graphics) while a smaller block size is better when handling e-mail and other common server data.



RAID 0 logical disks on FastTrak can have from one to four disk drives.

Mirror (RAID 1)

Writes duplicate data on to a pair of drives while reads are performed in parallel. RAID 1 is fault tolerant because each drive of a mirrored pair is installed on separate channels. If one of the mirrored drives suffers a mechanical failure or does not respond to the controller, the remaining drive will continue to function. Or, if one drive has a physical sector error, the mirrored drive will continue to function.



On the next reboot, the FastBuild™ Utility will display an error in the logical disk and recommend replacing the failed drive. You can continue using your PC, however Promise recommends replacing the failed drive as soon as possible.

Due to redundancy, the drive capacity of the logical disk is half the total drive capacity. For example, two 100 GB drives that have a combined capacity of 200 GB would have 100 GB of usable storage. With drives of different capacities, there may be unused capacity on the larger drive.

RAID 1 logical disks on FastTrak consist of two disk drives only.

Hot Spare Drive – For a RAID 1 logical disk, you can attach a third disk drive to the FastTrak card without assigning it to the logical disk. FastTrak will activate the drive and use it to replace a failed drive that was part of the mirrored logical disk. A rebuild operation copies the good drive data to the spare automatically and in the background.


At a later time, power off the system and replace the failed drive. Spare drives must be the same or larger capacity than the smallest logical disk member.

For more information on how to set up a hot spare drive, see page 68.

Mirror / Stripe (RAID 10)

A combination of RAID 0 and RAID 1 logical disks. It can increase performance by reading and writing data in parallel while protecting data with duplication. Four drives are required for this logical disk.

A RAID 10 logical disk starts with a mirrored pair of disk drives, like a RAID 1 logical disk. Then it stripes the data, like a RAID 0 logical disk, from the mirrored pair over two more disk drives. The data capacity is similar to a standard RAID 1 logical disk with half of the capacity used for redundancy.



Stripe Size – For RAID 10 logical disks you can manually select the stripe block size of 32, 64 or 128 MB. The default is 64 KB.

The size selected affects how FastTrak sends data blocks to and receives them from the drives. You must perform your own testing to determine how the data block size affects your particular use of the logical disk. In general, a larger block size is better when handling large data transfers (such as in A/V editing or graphics) while a smaller block size is better when handling e-mail and other common server data.

RAID 10 logical disks on FastTrak consist of four disk drives only.

Dual Data Redundancy

One unique (though rarely used) feature of RAID 10 is *dual* fault tolerance. In some cases, two drives can fail simultaneously yet the logical disk still maintains the integrity of data. There are six combinations in which two of the four drives can fail. The FastTrak Serial ATA RAID Controller protects the data in four of those cases depending on each drive's assignment in the logical disk.

Assume the drives are configured as follows:

- CH indicates channels (ports) on the FastTrak card.
- A/B indicates which mirrored pair the drive belongs to.
- 1/2 indicates which part of stripe data.

CH1	CH2	CH3	CH4
Drive A1	Drive A2	Drive B1	Drive B2

Under RAID 10, the logical disk maintains data integrity if any 1, 2 combination survives.

Event	Failed Drives	Logical Disk Status	Why?
1	A1/A2	Functional	B1/B2 retain logical disk integrity
2	B1/B2	Functional	A1/A2 retain logical disk integrity
3	A1/B2	Functional	B1/A2 retain logical disk integrity
4	B1/A2	Functional	A1/B2 retain logical disk integrity
5	A1/B1	Offline	B2/A2 contain only half of the data
6	B2/A2	Offline	A1/B1 contain only half of the data

Choosing a RAID Level

There are several issues to consider when choosing the RAID Level for your FastTrak logical drive. The following discussion summarizes some advantages, disadvantages and applications for each choice.

RAID 0

Advantages	Disadvantages
Implements a striped disk logical drive, the data is broken down into blocks and each block is written to a separate disk drive I/O performance is greatly improved by spreading the I/O load across many channels and drives No parity calculation overhead is involved	Not a true RAID because it is not fault-tolerant The failure of just one drive will result in all data in an logical drive being lost Should not be used in mission critical environments

Recommended Applications for RAID 0

- Image Editing
- Pre-Press Applications
- Any application requiring high bandwidth

RAID 1

Advantages	Disadvantages
Simplest RAID storage subsystem design Can increase read performance by processing data requests in parallel since the same data resides on two different drives	High disk overhead - uses only 50% of total capacity

Recommended Applications for RAID 1

- Accounting
- Payroll
- Financial
- Any application requiring very high availability

RAID 10

Advantages	Disadvantages
Implemented as a mirrored logical drive whose segments are RAID 0 logical drives High I/O rates are achieved thanks to multiple stripe segments	High disk overhead - uses only 50% of total capacity

Recommended Applications for RAID 10

- Imaging applications
- Database servers
- General fileserver

JBOD

Advantages	Disadvantages
Easy management of multiple independent disk drives	No increase in performance, capacity or fault tolerance.

Recommended Applications for JBOD

- Non-critical file storage
- Swappable data storage

Expand or Convert a Logical Disk

To expand a logical disk means to add more disk drives to it. To convert, (sometimes called “migrate”) a logical disk means to change its RAID Level. Both of these operations are possible while the existing logical drive remains online and available for data read/write functions.

Different types of logical drives use different organizational models and have varying benefits. The following outline breaks down the properties for each type of RAID supported by Promise products.

From	To	Increase		Redundancy	
		Capacity	Performance	Add	Lose
RAID 10	RAID 0	•	•		•
RAID 1	RAID 10	•	•		
	RAID 0	•	•		•
RAID 0 multi-disk	RAID 10	•	•	•	
	RAID 0	•			
RAID 0 single disk	RAID 10	•	•	•	
	RAID 1			•	
	RAID 0	•			

The table above shows the available RAID Level conversions possible with Fastrak TX4200.

The FastTrak 2200, because it has only two channels, only supports conversion from a single-drive RAID 0 to a two-drive RAID or to single-drive RAID 0 a RAID 1 logical disk.

Appendix A: Partition and Format

In order for your operating system to recognize and work with the disk drives attached to your FastTrak TX2200 or TX4200 Serial ATA RAID Controller card, the drives must be partitioned and formatted.


- If your drives were previously partitioned and formatted they are ready to use and you can skip this procedure
- If your drives have not been partitioned and formatted, you must do that job before you can use them

The actions of partitioning and formatting create a file structure on the disk drives with which your operating system can work. In the example below, we show how this is done in Windows. A similar procedure is required for Linux PC's. However, partitioning and formatting in Linux is unautomated, therefore please refer to your system documentation for the exact procedure.




Note


If you plan to boot your computer from this logical disk, go to Windows and Device Driver Installation under the Installation section for instructions. The instructions here are for data logical disks only.




1. From the desktop, right-click on the My Computer icon and select Manage from the popup menu. The Computer Management window opens.
2. From the left menu, click on Disk Management. The Disk Management window opens with your new logical disk identified as Disk 1. The Initialize Wizard appears automatically.



3. Click the Next button to start the Wizard.
4. In the following windows, select Disk 1 to Initialize. Do not select any disks to Convert. Click the Finish button to Initialize the logical disk.




5. Right-click on the Unallocated portion of Disk 1 and select New Partition... from the popup menu. The New Partition Wizard appears.



6. Click the Next button to start the wizard.
7. In the following windows, do the following actions. Click Next to move to the next window.
 - Select Primary Partition
 - Specify the maximum available partition size in MB
 - Assign the available drive letter of your choice
 - Choose Format this partition with the following settings
 - File system: NTFS
 - Allocation unit size: Default
 - Volume label: Enter your choice of name
 - Do not check "Perform a quick format" or "Enable file and folder compression"
8. Review your selections and click Finish. The New Partition Wizard will disappear while partitioning and formatting begin.

This process will take some time. The Disk Management window displays the progress.



When formatting is complete, your logical disk will appear as a hard drive in the Disk Management window (above) and the My Computer window (below).

