

JUMPER	PIN DEFINITION	
J2	Display Type Select Open Short	Mono/EGA/VGA (default) Color
J3	External, Internal Battery Select 1-2 2-3	External battery Internal battery (default)
J4	Local IDE Select 1-2 2-3	Enable Disable
JP4	Local IDE 1-2 2-3	Default For VESA Local VGA Card installed at VESA slot 0 only
J5, J6	HDD Speed Select (PDC 20230 Only) IDE Type Speed 0 Speed 1 Speed 2	J5 J6 2-3 2-3 1-2 2-3 (default) 1-2 1-2
J7	Password Clear Short Open	Clear password (default)
J9	HDD_BALE Short Open	Enable Disable (default)
J10	HDD_IOCHRDY Short Open	Enable Disable (default)
J18	Short Open	Adaptec ISA Master 1542B/C SCSI card only (Transfer rate $\geq$ 5.7MB/s) Default (Transfer rate $<$ 5.7MB/s)
JC7	80486SX/P23S/P4S/Cx486S PQFP Select Short Open	Disable Enable
JT1	P24T/P24CT Write-back/Write-through Select Short Open	Write-back Write-through

Table 2-2. Jumper Definitions



**NOTE :** Users are not encouraged to change the jumper settings not listed in this manual as they are considered factory defaults which may adversely affect system performance.