

## Table of Contents

### Chapter 1 Overview

Package Checklist .....	1
The KLI-6130 Motherboard.....	2
Main Features.....	3

### Chapter 2 Installation Procedures

1). Set System Jumpers .....	6
Motherboard Layout.....	7
Enabling Clear Password Function: CPW.....	8
Enabling CMOS Clear Function: CMOS_CLR.....	8
Flash ROM Type Selection: EP.....	9
Disabling Onboard VGA Feature: VGA_Dis.....	9
2). Install RAM Modules.....	10
RAM Module Configuration.....	10
Install and Remove DIMMs.....	11
3). Install the CPU Module.....	12
Celeron CPU Module Installation.....	12
Pentium II CPU Module Installation .....	13
CPU to Bus Frequency Ratio: FREQ .....	18
Table of CPU Frequencies.....	18
4). Install Expansion Cards .....	19
5). Connect Devices .....	20
Connect to Internal Devices.....	20
Floppy Diskette Drive Connector: FLOPPY .....	20
IDE HDD Device Connectors: PRIMARY, SECONDARY .....	20
ATX Power Connector: ATX_PWR .....	21
CPU Fan Connector: CPU_FAN .....	21
Wake-On-LAN Connector: RWU.....	22
ATI Multimedia Channel Connector: AMC.....	22
Connect to System Case .....	23
Front Panel Block Connector: V_PNL.....	23
Chassis Fan Connector: CHASS_FAN1, CHASS_FAN2 .....	24
Connect to External Devices.....	25
Serial Port Connectors: COM1, COM2 .....	25
PS/2 Keyboard Connector, PS/2 Mouse Connector: KB/MS ...	25
Printer Connector: LPT.....	26
Universal Serial Bus Connectors: USB1, USB2, USB3 .....	26



---

## Table of Contents

---

Audio I/O Jacks: LINE_OUT, LINE_IN, MIC_IN.....	27
Joystick/MIDI Connector: GAME .....	27
Infrared Connector: IR .....	28
CD-ROM Drive Audio-Out Connector: CD_IN .....	28

### **Chapter 3 BIOS Setup**

CMOS Setup Utility.....	29
Standard CMOS Setup .....	30
Hard Disk Configurations.....	30
Software Turbo Speed .....	31
BIOS Features Setup.....	31
Chipset Features Setup.....	34
Power Management Setup.....	37
PNP/PCI Configuration .....	40
Load BIOS Defaults .....	41
Load Setup Defaults.....	41
Integrated Peripherals .....	42
Supervisor/User Password.....	45
IDE HDD Auto Detection.....	46
Save and Exit Setup .....	46
Exit without Saving.....	46

### **Chapter 4 Software Utilities**

Starting Installation.....	47
LANDesk Client Manager (manufacturing option).....	47
LDCM 3.21 Specification Overview.....	47
Two Options of LDCM Setup.....	48
Desktop Management Interface (DMI).....	49
Starting DMI.....	49
Editing DMI.....	49
Adding DMI.....	49
Loading DMI .....	49
Saving DMI .....	49
Bus Master IDE Driver .....	50
Installation.....	50
Patch for Chipset.....	50
Installation.....	50

BIOS Flash Software.....	51
Downloading BIOS File .....	51
Upgrading BIOS File.....	51
Loading New BIOS Defaults .....	52
Anti-Virus Tool.....	52
Hardware Requirements.....	52
Technical Notes .....	52
ATI Video Driver .....	53
ESS Audio Driver .....	56
 <b>Appendix     An Example of Fan Installation</b>	
.....	57

**This Page Intentionally Left Blank**