


BIOS Setup

The mainboard comes with an AMI BIOS chip that contains the ROM Setup information of your system. This chip serves as an interface between the processor and the rest of the mainboard components. This chapter explains the information contained in the Setup program and tells you how to modify the settings according to your system configuration.

Main Setup



The Main Setup screen is displayed above. Each item may have one or more option settings. It allows you to change the system Date and Time, IDE hard disk, floppy disk drive types for drive A: and B:.

Auto-Detect Hard Disks

Allows the system BIOS to detect all hard disk parameters automatically.

Boot Sector Virus Protection


When Enabled, a warning will be given when any program or virus sends a Disk Format command or tries to write to the boot sector of a hard disk drive.

Advanced Setup



Advanced Setup options are displayed by choosing item from the AMI BIOS Setup main menu. All Advanced Setup options are described in their corresponding operating menus by brief Setup Helps.

Security Setup



Set Supervisor and User Passwords: You can set either a Supervisor password or a User password. If you do not use a password, just press **Enter** when the password prompt appears. The password check option is enabled in Advanced Setup by choosing either Always (the password prompt appears every time the system is powered on) or Setup (the password prompt appears only when AMI BIOS is run). You can enter a password by typing the password on the keyboard. When you select Supervisor or User, AMI BIOS prompts for a password. You must set the Supervisor password before you can set the User password. Enter a 1 to 6 character password. The password does not appear when typed.

Changing a Password: Enter the password and press **Enter**. After the new password is entered, retype the new password as prompted and press **Enter**. If the password confirmation is incorrect, an error message appears. If the new password is entered without error, press to return to the AMI BIOS Main Menu.

Exit Setup



Exit Saving Changes allows you to write the current settings to CMOS and exit.

Exit Discarding Changes allows you to exit without writing the current settings to CMOS.

Load Optimal Settings is selected for settings which provide the best system performance.

Load Fail Safe Settings is for settings that provide a more efficient computer. If the computer will not boot, select this option and try to diagnose the problem after the computer boots. These settings do not give optimal performance.

Load Original Values recalls your last set of previous settings. This option is convenient if you change settings and decide you wish to return to the previous settings.