

## Table of Contents

### Chapter 1 Overview

Package Checklist.....	1
The CP31-AG Mainboard.....	2
Main Features .....	3
Advanced Features .....	5
Intel LANDesk Client Manager (optional) .....	6
LDCM Key Features .....	6

### Chapter 2 Installation Procedures

Quick Reference.....	8
1). Set System Jumpers/Switches.....	10
Mainboard Layout .....	13
Clear CMOS: SW1-5 .....	13
Clear Password: SW1-6 .....	13
Flash ROM Type Selection: EP.....	14
Keyboard Wake-up Selection: KEY_WAKE .....	14
Onboard VGA Feature Selection: VGA_DIS .....	15
Onboard Audio Feature Selection: AUD_DIS.....	15
2). Install RAM Modules .....	16
SDRAM Memory .....	16
Install and Remove DIMMs .....	17
3). Install the CPU.....	18
CPU Internal Frequency Selection: SW-1/-2/-3/-4 .....	19
4). Install Expansion Cards .....	20
5). Connect Cables and Power Supply.....	22
PS/2 Keyboard and Mouse Connector: KB and MS.....	22
Universal Serial Bus Connectors: USB0, USB1, USB2.....	23
Printer Connector: LPT .....	23
Serial Port Connectors: COM1, COM2.....	24
Video Graphics Accelerator Connector: VGA .....	24
Joystick/MIDI Connector: GAME.....	25
Audio I/O Jacks: L_IN, L_OUT, MIC_IN .....	25
CPU Fan Connector: CPU_FAN.....	26

## CP31-AG Mainboard Manual

---

System Case Fan Connectors: CHS_FAN1, CHS_FAN2.....	26
Power Fan Connector: PWR_FAN.....	27
Wake-On-LAN Connector: WOL.....	27
System Chassis Intrusion Alarm Connector: CHASSIS.....	27
ATX Power Connector: POWER.....	28
Floppy Diskette Drive Connector: FDD.....	28
CD-ROM Drive Audio-out Connector: CD_IN1, CD_IN2.....	29
IDE HDD Device Connectors: PRIMARY, SECONDARY.....	29
ATI Multimedia Channel Connector: AMC.....	30
Front Panel Block Connector.....	30
Infrared Connector: IR.....	31
Digital Front Panel Connector: DFP (optional).....	32

### Chapter 3 BIOS Setup

Main Setup.....	33
Advanced Setup.....	34
Security Setup.....	35
Exit Setup.....	36

### Chapter 4 FAQs

General FAQs.....	37
BIOS FAQs.....	40
Windows 98 FAQs.....	41
Windows 95 FAQs.....	42
Intel CPU FAQs.....	43