

## Table of Contents

### Chapter 1 Overview

Package Checklist .....	2
Main Features .....	3
Advanced Features .....	5
PC '97 Compliant .....	7
Infrared (IR) Connections .....	8
Highly Convenient Integrated I/O Connectors .....	9

### Chapter 2 Installation Procedures

Mainboard Layout .....	12
1). Set System Jumpers .....	13
Jumpers .....	13
Clear Password: CPW .....	13
Flash EPROM Type Selection: EP1, EP2 .....	14
CPU to SRAM Data Transacting Mode Selection: SRAM .....	14
2). Install System RAM Modules .....	15
DRAM and SDRAM .....	15
RAM Module Configuration .....	16
Install SIMMs .....	17
Remove SIMMs .....	17
Install DIMMs .....	18
Remove DIMMs .....	18
Cache Memory .....	19
Onboard Cache RAM (256KB/512KB) .....	19
3). Install the CPUs .....	20
CPU External Clock (Bus) Frequency: CLK1, CLK2, CLK3 ..	21
CPU to Bus Frequency Ratio: FREQ1, FREQ2, FREQ3 .....	22
Intel Pentium CPUs .....	23
Frequency .....	23
Voltage .....	24
AMD-K5/K6 CPUs .....	25
Frequency .....	25
Voltage .....	26
Cyrix 6x86 CPUs .....	27
Frequency .....	27
Voltage .....	28

IBM 6x86 CPUs .....	29
Frequency.....	29
Voltage.....	30
4). Install Expansion Cards .....	31
5). Connector Cables and Power Supply .....	33
Serial Port Connectors: COM1, COM2 .....	33
CPU Fan Connector: FAN.....	33
Floppy Diskette Drive Connector: FLOPPY .....	34
Front Panel Block Connector: F_PNL .....	35
Infrared Connector: IR .....	36
PS/2 Keyboard Connector: PS2_KB .....	36
PS/2 Mouse Connector: PS2_MS .....	37
ATX Power Connector: PWR1 .....	37
Standard Power Connector: PWR2.....	38
IDE HDD Device Connectors: PRIMARY, SECONDARY .....	38
Printer Connector: PRINTER .....	39
Remote Power Supply Connector: RPW_CON .....	39
Universal Serial Bus Connector: USB0, USB1 .....	40

### **Chapter 3   Award BIOS Setup**

CMOS Setup Utility.....	41
Standard CMOS Setup .....	42
Hard Disk Configuration .....	42
BIOS Features Setup.....	44
Chipset Features Setup.....	47
Power Management Setup.....	52
PCI Configuration Setup.....	55
PnP Configuration Setup .....	57
Load BIOS Defaults .....	58
Load Setup Defaults.....	58
Supervisor/User Password.....	58
IDE HDD Auto Detection.....	59
Save and Exit Setup .....	60
Exit without Saving.....	60

### **Appendix   BIOS Update Instruction**

Flash Process .....	61
---------------------	----

**Appendix B ICW/PhaseLink Clock Generator**

CPU External Clock (Bus) Frequency: CLK1, CLK2, CLK3.....	63
Intel Pentium CPUs.....	64
Frequency .....	64
AMD-K5/K6 CPUs.....	65
Frequency .....	65
Cyrix 6x86 CPUs.....	66
Frequency .....	66
IBM 6x86 CPUs.....	67
Frequency .....	67

**This Page Intentionally Left Blank**