

Table of Contents

Chapter 1 Overview

Package Checklist.....	2
Main Features	3
Advanced Features	5
PC '97 Compliant	7
Infrared (IR) Connections	8
Highly Convenient Integrated I/O Connectors.....	9

Chapter 2 Installation Procedures

Mainboard Layout	12
1). Set System Jumpers.....	13
Jumpers	13
Clear Password: CPW	14
Flash EPROM Type Selection: EP1, EP2.....	14
CPU to SRAM Data Transacting Mode Selection: SRAM	15
2). Install System RAM Modules	16
DRAM and SDRAM.....	16
RAM Module Configuration.....	17
Install SIMMs	18
Remove SIMMs	18
Install DIMMs.....	19
Remove DIMMs	19
Cache Memory.....	20
3). Install the CPUs	21
CPU External Clock (Bus) Frequency:	
CLK1, CLK2, CLK3	22
CPU to Bus Frequency Ratio:	
FREQ1, FREQ2, FREQ3	23
Intel Pentium CPUs.....	24
Frequency.....	24
Voltage	25
AMD-K5/K6 CPUs.....	26
Frequency.....	26
Voltage	27
Cyrix 6x86 CPUs	28
Frequency.....	28
Voltage.....	29

IBM 6x86 CPUs.....	30
Frequency.....	30
Voltage.....	31
4). Install Expansion Cards.....	32
5). Connector Cables and Power Supply	34
Serial Port Connectors: COM1 and COM2.....	34
CPU Fan Connector: CPU_FAN	34
Floppy Diskette Drive Connector: FLOPPY.....	35
Infrared Connector: IR	35
Front Panel Block Connector: F_PNL	36
PS/2 Keyboard Connector: PS2_KB.....	37
PS/2 Mouse Connector: PS2_MS	37
ATX Power Connector: ATX_PWR.....	38
Standard Power Supply Connector: AT_PWR.....	38
IDE HDD Device Connectors:	
PRIMARY and SECONDARY.....	39
Printer Connector: PRINTER	39
Remote Power Supply Connector: RPW_CON	40
Universal Serial Bus Connectors: USB1 and USB2	40

Chapter 3 AMI BIOS Setup

Main Setup	41
Advanced Setup.....	42
Advanced CMOS Setup	43
Advanced Chipset Setup	47
Power Management Setup.....	50
Plug and Play Setup	53
Peripheral Setup.....	56
Security Setup.....	58
Exit Setup	60

Appendix A BIOS Update Instruction

Flash Process	61
---------------------	----

Appendix B ICW/PhaseLink Clock Generator

CPU External Clock (Bus) Frequency:	
CLK1, CLK2, CLK3	63
Intel Pentium CPUs	64
Frequency	64
AMD-K5/K6 CPUs	65
Frequency	65
Cyrix 6x86 CPUs.....	66
Frequency	66
IBM 6x86 CPUs	67
Frequency	67

This Page Intentionally Left Blank