

Universal Serial Bus Connector: USB1, USB2

It connects to the port that allows you to attach with a USB hub. Please refer to Page 4-9 for the related BIOS information.

The devices related to this feature, are not available for testing when this manual was printed.

