

## Table of Contents

### Chapter 1 Overview

|                     |   |
|---------------------|---|
| Main Features ..... | 2 |
|---------------------|---|

### Chapter 2 Installation Procedures

|   |    |
|---|----|
| Mainboard Layout .....                                  | 4  |
| 1). Set System Jumpers .....                            | 5  |
| Flash ROM Voltage Select: EP1 and EP2 .....             | 5  |
| CPU to SRAM Data Write Mode Selection: SRAM1 .....      | 5  |
| Clear Password: CPW .....                               | 6  |
| PCI 2 ID: PCI2ID .....                                  | 6  |
| 2). Install DRAM Modules .....                          | 7  |
| DRAM Configuration .....                                | 7  |
| Installation Instructions .....                         | 8  |
| Remove SIMMs .....                                      | 8  |
| Cache Memory .....                                      | 9  |
| 3). Install the CPUs .....                              | 10 |
| CPU to Bus Frequency Ratio:                             |    |
| FREQ1 and FREQ2 .....                                   | 11 |
| CPU External Clock (Bus) Frequency: CLK1 and CLK2 ..... | 12 |
| CPU Voltage Selection: VR1 and VR2 .....                | 13 |
| CPU Voltage Markings .....                              | 14 |
| Installation of Cyrix (or IBM) 6x86 CPU Fan .....       | 15 |
| 4). Connect Cables and Power Supply .....               | 16 |
| Serial Port Connectors: COM1 and COM2 .....             | 16 |
| CPU Fan Connectors: FAN .....                           | 16 |
| Block Connector .....                                   | 17 |
| Power Connector: POWER .....                            | 18 |

### Chapter 3 Award BIOS Setup

|                              |    |
|------------------------------|----|
| CMOS Setup Utility .....     | 19 |
| Standard CMOS Setup .....    | 20 |
| BIOS Features Setup .....    | 22 |
| Chipset Features Setup ..... | 25 |
| Power Management Setup ..... | 28 |

VA-501 Mainboard Manual

---

PCI Configuration Setup..... 31

PnP Configuration Setup ..... 33

Load BIOS Defaults ..... 34

Load Setup Defaults..... 34

Supervisor/User Password..... 34

IDE HDD Auto Detection..... 35

Save and Exit Setup ..... 36

Exit without Saving..... 36