

SAFETY INSTRUCTIONS

Battery Warning

WARNING : The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion and risk of personal injury if the battery is incorrectly replaced or mistreated. Do not attempt to recharge the battery, disassemble it, remove it, immerse it in water, or dispose of it in fire.

This computer has been tested for conformity to international safety regulations. Like any electronic device, however, the computer should be used with care. To protect yourself from possible injury and to minimize the risk of damage to the computer, read and follow these safety instructions:

General Guidelines

- Read all of these instructions.
- Save these instructions for later use.
- Follow all warnings and instructions marked in the computer.
- Except as explained elsewhere in this manual, do not attempt to service the computer yourself. Opening or removing these covers that are marked “Do Not Remove” might expose you to dangerous voltage points or other risks. Refer all servicing of marked compartments to a qualified personnel.

Installation Restrictions

- Do not use the computer near water.
- Do not place the computer on an unstable cart, stand, or table. The computer might fall and be seriously damaged.
- Do not block or cover the ventilation slots on the cover or cabinet of the computer. Air must be allowed to circulate through these slots in order to ensure that the computer operates properly and does not overheat.
- Install the computer near an electrical outlet for ease of access. Use the plug of the power cord to disconnect power from the computer.
- Do not place the computer near or over a radiator or heat register or in direct sunlight. Place the computer in a small enclosure only if proper ventilation is provided.
- Do not permit anything to rest on the power cord. Do not locate the computer where people can walk on its power cord.
- Do not plug the computer into the same circuit with radio or television receivers.

- Wear a static wrist strap which fits around your wrist and is connected to a natural earth ground.
- Touch a grounded or anti-static surface or a metal fixture such as a water pipe.
- Avoid contacting the components on add-on cards, boards and modules and the “gold finger” connectors plugged into the expansion slot. It is best to handle system components by their mounting bracket.

Electrical Restrictions

WARNING : This equipment is designed for connection to a grounded (earthed) outlet. The grounding type plug is an important safety feature. To reduce the risk of electrical shock, damage to your equipment, or loss of your data, do not disable this feature.

Power Cord Set Requirements

The power cord set (appliance coupler, flexible, and wall plug) you received with your computer meets the requirements for use in the country where you purchased your equipment.

Power cord sets for use in other countries must meet the requirements of the country where you use the computer. For more information on power cord set requirements, contact your FIC authorized dealer, reseller, or service provider.

General Requirements

The requirements listed below are applicable to all countries:

1. The length of the power cord set must be at least 6.00 feet (1.8 m) and a maximum of 9.75 feet (3.0 m).
2. All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be used.
3. The power cord set must have a minimum current capacity of 10A and a normal voltage rating of 125 or 250 volts AC, as required by each country's power system.
4. The appliance coupler must meet the mechanical configuration of an EN 60 320./IEC 320 Standard Sheet C13 connector, for mating the appliance inlet on the computer.

Country-Specific Requirements

Power Cord Set Requirement		
<i>Country</i>	<i>Accredited Agency</i>	<i>Applicable Note Numbers</i>
Australia	EANSW	1
Austria	OVE	1
Belgium	CEBC	1
Canada	CSA	2
Denmark	DEMKO	1
Finland	FIMKO	1
France	UTE	1
Germany	VDE	1
Italy	IMQ	1
Japan	JIS	3
The Netherlands	KEMA	1
Norway	NEMKO	1
Sweden	SEMKO	1
Switzerland	SEV	1
United Kingdom	BSI	1
United States	UL	2

NOTE:

- Flexible cord must be <HAR> Type HO5VV-F, 3-conductor. 1.0 mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
- Flexible cord must be Type SVT or equivalent. NO. 18 AWG, 3-conductor. Wall plug must be a two-pole grounding type with a NEMA 5-15P (15A, 125V) or NEMA 6-15P (15A 250V) configuration.
- Appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 0.75mm² conductor size. Wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (15A, 125V) configuration.

Battery (Lithium)

NOTE : The following caution statement is located in the service and operating manual or adjacent the battery.

1. English

"CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS"

2. French

IL Y A DANGER D'EXPLOSION S'IL Y A REMPLACEMENT INCORRECT DE LA BATTERIE. REMPLACER UNIQUEMENT A VEC UNE BATTERIE DU MÊME TYPE OU D'UN TYPE RECOMMANDÉ PAR LE CONSTRUCTEUR. METTER AU RÉBUT LES BATTERIES USAGÉES CONFORMÉMENT AUX INSTRUCTIONS DU FABRICANT"

3. German

"VORSICHT ! Explosionsgefahr bei unsachgemäßen Austausch der Batterie. Ersatz nur durch denselben oder einem vom Hersteller empfohlenem ähnlichen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

4. Swedish

" Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion. "
(If the battery is placed in an area not accessible to the user even English text can be used.)

5. Danish

" Lithiumbatteri- Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Lever det brugte batteri tilbage til leverandoren. "
(The size of the warning must be a minimum of 26x52 mm., the background shall be yellow color with black frame, and the text in black color. A white background is acceptable in the User's instruction and in the Service Manual.)

6. Norwegian

“ Eksplosjonsafe ved feilaktig skifte av batteri. Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabriknten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner. “
(Danish or Swedish text can also be accepted.)
(If the battery is placed in an area not accessible to the user even English text can be used.)

7. Finnish

“ Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainostaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käyteet paristo valmistajan ohjeiden mukaisesti. “
(If the battery is placed in an area accessible to the user, the warning text has to be both in Swedish and Finnish.)
(If the battery is placed in an area not accessible to the user, even Swedish or English text can be used.)

Operating and Maintenance Guidelines

- Never spill liquids or push objects of any kind into the computer through cabinet slots. Liquids and foreign objects might touch dangerous voltage points or short out parts, creating a risk of fire or electrical shocks.
- Keep the area around the computer free from static electricity and magnetic fields. Before you touch the computer, discharge static electricity on your body by touching a metallic surface.
- Operate the computer only when the cover is in the closed position.
- Do not turn the computer on and off in rapid succession. Doing so might damage data in the configuration files and on the hard fixed disk drive.
- Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls might result in damage and often requires extensive work by a qualified technician to restore the product to normal operation.
- Clean the display and computer periodically with a damp cloth. Do not use liquid or aerosol cleanser. Unplug the computer from its electrical outlet before cleaning it.
- Prepare the computer before moving it by taking the following actions:
 - Lock the cabinet cover.
 - Insert an old diskette in each floppy diskette drive.
 - Disconnect external peripheral devices.

- Unplug the computer from the wall outlet and refer servicing to qualified service personnel under any of the following conditions:
 - The cord or plug is damaged or frayed.
 - Liquid has been spilled into the computer.
 - The computer has been exposed to rain or water.
 - The computer does not operate normally even when the operating instructions are followed.
 - The computer has been dropped or the cabinet has been damaged.
 - The computer exhibits a distinct change in performance, indicating a need for servicing.