



⚠ Attention!



1. Open both clip levers.
2. Insert flat head screwdriver between fan shroud and clip frame. Push screwdriver down until it hits the clip hook.



3. Push down on the clip hook and simultaneously rotate the screwdriver towards the fan heatsink to free the clip hook from the retention mechanism (RM). Repeat this process for the remaining clip hooks. Then, remove the fan heatsink.

Copyright © Intel Corporation 2002.

Part Number C14157-001
First Edition September 2002