



## Installing the SuperCheck Remote Monitoring Utility in Windows NT 4.0

To speed up the **SuperCheck Installation** process of the **SuperCheck Remote Monitoring Utility** we recommend copy all of the files from the Two floppy disks to a folder on your desktop.

- Right click on the Desktop, select **"New Folder"**, and then type **"SuperCheck"** (any name you desire, this folder is temporary) for the folder name.
- Insert **Diskette number 1**, then double click on **"My Computer"**, and then double click on the **"3 1/2 Floppy (A:)"**.
- Select **"Edit"** from the menu and then select **"Select All"**. Next select **"Edit"** from the menu and then select **"Copy"**.
- Minimize the **"My Computer"** Window and then right click on the **"SuperCheck Folder"** (or folder of your choice) and select **"Paste"**. When file copy is complete, repeat the copy and paste process (**to the same folder as the first disk**) for the **Diskette 2**.
- Double Click on the **"SuperCheck"** (of folder of your choice) and then double click on **"setup"**, not **"isSetup"**.
- Select number **4**, **"Install All Components"** to begin the SuperCheck installation process for **3 vital** components, (in this order) the **"Remote Monitoring Utility"**, the **"Message Server"**, and the **"Message Agent"**. All three components must be installed for the **SuperCheck Remote Monitoring Utility** to work properly.
- Click on **"Next"** at the **"Choose Destination Location"** dialog box. Click on **"Next"** at the **"Select Program Folder"** and then **"Next"** at the **"Start Copying Files"** dialog box.
- After the brief file copy, you will be presented with the **"Install Message Server for Monitoring Utility"** dialog box. Enter the **I.P. Address** for the machine that contains the **SuperTrak66/SuperTrak Pro** and change (if desired) the **Server Description** to a name of your choice and the click on **"Next"**.  
**NOTE: If Machine that contains the SuperTrak66/SuperTrak Pro is not on a Local Network or does not have a Network Card, leave the IP Address with the default setting of "127.0.0.1". Also under your TCP/IP settings (if applicable), the IP Address tab has two options, "Obtain an I.P. address from a DHCP Server" and "Specify an IP Address". Select "Obtain an IP Address from a DHCP Server".**
- Click on **Finish** to end the **"SuperCheck Remote Monitoring Utility"** Portion of the Install.
- Next the **"Promise RAID Message Server"** install will begin.
- Click on **"Next"** at the **"Choose Destination Location"** dialog box. Click on **"Next"** at the **"Select Program Folder"** and then **"Next"** at the **"Start Copying Files"** dialog box.

- Click on **"Finish"** when the **"SuperCheck Installation Utility"** dialog box appears.
- Next the **"Promise RAID Message Agent"** Install will begin automatically. Click **"Next"** at the **"Choose Destination Location"** dialog box.
- Click on **"Next at the "Select Program Folder"** and then select **"Next"** at the **"Start Copying Files"** dialog box.
- After the brief file copy, the **"Add User Account for Administration"** dialog box will appear. We recommend leaving the name at **"Administrator"**, but you may enter any name that you choose.
- Enter a **"Password"** in the Password box, and re-enter the Password in the **"Confirm Password"** Box. Click on **"Next"** when finished. Click on **"Finish"** when the **"SuperCheck Installation Utility"** dialog box appears.
- View the **"Readme"** files that have opened after the installs and then restart the computer.