







Low-Voltage CPU Jumper Settings

CPU Voltage Type	Jumper Setting	CPU Model
3.3V	 JVC2 JVC1 1	<p>UMC - AMD - U5SLV-SUPERXX AMD-X5</p> <p>AMD - A80486DX4-100NV8T A80486DX2-XXSV8B A80486DX2-XXNV8T Am486DX2-XXV8T A80486DX4-XXSV8B Am486DX4-100V8T Am486DX4-XXV16BXX</p>
3.45V	 JVC2 JVC1 1	<p>Intel 486 - A80486DX4-75 A80486DX4-100</p> <p>Cyrix - 5x86-100 5x86-120 M1sc-100 M1sc-120</p> <p>TI - DX2-80 DX4-100</p>
3.59V	 JVC2 JVC1 1	<p>Cyrix - Cx486DX-VXXGP Cx486DX2-VXXGP</p>
4.0V	 JVC2 JVC1 1	<p>Cyrix - Cx486DX2-V80GP</p>
CN_3V	 	<p>For 3.3V, 3.46V, 3.59V and 4.0V CPUs</p> <p>For 5.0V CPUs (Default)</p>