





**Password Clear: JCP**



**Display Type Select: VIDEO**


**KB\_LOCK Mode Select: J2**

**TB\_LED Mode Select: J3**

Password Clear	JCP
Enabled	
Disabled (Default)	

KB_LOCK Mode	J2
IOCHCK	
KB_LOCK (Default)	

Display Type	VIDEO
Mono/EGA/VGA (Default)	
CGA	

TB_LED Mode	J3
G_LED	
TB_LED (Default)	