

Table of Contents

Chapter 1 Installation Procedures

Clear CMOS: SW1-5	2
Clear Password: SW1-6	2
Flash ROM Type Selection: EP1, EP2	3
CPU Internal Frequency Selection: SW-1, SW-2, SW-3, SW-4.	4

Chapter 2 BIOS Setup

CMOS Setup Utility	5
Standard CMOS Setup.....	6
Hard Disk Configurations	6
Software Turbo Speed	7
BIOS Features Setup	8
Chipset Features Setup	11
Power Management Setup	15
PNP/PCI Configuration.....	20
Load BIOS Defaults.....	22
Load Setup Defaults	22
Integrated Peripherals	23
Supervisor/User Password	27
IDE HDD Auto Detection	28
Save and Exit Setup.....	29
Exit without Saving	29
