

Table of Contents

Chapter 1 Overview

Package Checklist.....	1
The KBI-6130-V Mainboard.....	2
Main Features	3
Manufacturing Optional Features.....	5

Chapter 2 Installation

Mainboard Layout	8
1). Set System Jumpers/Switches	10
Clear CMOS: SW1-5	10
Clear Password: SW1-6	10
Flash ROM Type Selection: EP.....	11
Keyboard Wake-up Selection: KEY_WAKE	11
Onboard VGA Feature Selection: VGA_DIS	12
Onboard Audio Feature Selection: AUD_DIS.....	12
2). Install RAM Modules	13
SDRAM Memory	13
Install and Remove DIMMs	14
3). Install the CPU	15
I). Install with Foldable Retention Mechanism Assembly	16
II). Install with Non-Foldable Retention Mechanism Assembly	17
CPU Internal Frequency Selection:	
SW-1, SW-2, SW-3, SW-4.....	20
4). Install Expansion Cards	21
5). Connect Devices.....	23
Connectors	23
System Case Fan Connector: CHA_FAN1, CHA_FAN2	23
Serial Port Connectors: COM1, COM2.....	24
PS/2 Keyboard and Mouse Connector: KB, MS	24
Printer Connector: LPT	25
System Chassis Open Alarm Connector: CHASSIS	26
Floppy Diskette Drive Connector: FLOPPY	26
SPDIF Connector: SPDIF (optional)	26
IDE HDD Device Connectors: PRIMARY, SECONDARY.....	27
ATX Power Connector: POWER	27
Power Fan Connector: PWR_FAN.....	28
CPU Fan Connector: CPU_FAN.....	28

Wake-On-LAN Connector: WOL.....	29
Front Panel Block Connector.....	29
Universal Serial Bus Connectors:	
USB0, USB1, USB2 (optional)	31
PCI Audio Card Connector: SB_LINK.....	31
Infrared Connector: IR.....	32
CD-ROM Drive Audio-out Connector: CD_IN1, CD_IN2	32
Joystick/MIDI Connector: GAME.....	33
Audio I/O Jacks: L_IN, L_OUT, MIC_IN	33
Video Graphics Accelerator: VGA.....	34
ATI Multimedial Channel Connector: AMC	34

Chapter 3 BIOS Setup

CMOS Setup Utility	35
Standard CMOS Setup.....	36
Hard Disk Configurations	36
Software Turbo Speed	37
BIOS Features Setup	37
Chipset Features Setup (for KBI-6130 only).....	41
Chipset Features Setup (for KBI-6130-V only).....	44
Power Management Setup (for KBI-6130 only).....	47
Power Management Setup (for KBI-6130-V only)	52
PNP/PCI Configuration (for KBI-6130 only)	56
PNP/PCI Configuration (for KBI-6130-V only)	58
Load BIOS Defaults.....	60
Load Setup Defaults	60
Integrated Peripherals (for KBI-6130 only)	61
Integrated Peripherals (for KBI-6130-V only).....	63
Supervisor/User Password	69
IDE HDD Auto Detection	69
Save and Exit Setup.....	70
Exit without Saving	70

Chapter 4 FAQs

General FAQs.....	71
BIOS FAQs	74
Windows 98 FAQs	75

Table of Contents

Windows 95 FAQs	76
Input CPU FAQs	77

This Page Left Blank for Note