

Table of Contents

Chapter 1 Installation Procedures

Clear Password: SW1-6.....	2
Clear CMOS: SW1-5.....	2
Flash EPROM Type Selection: EP1, EP2.....	3
CPU Internal Frequency: SW1-1, SW1-2, SW1-3, SW1-4.....	4

Chapter 2 BIOS Setup

CMOS Setup Utility.....	5
Standard CMOS Setup.....	6
Hard Disk Configurations.....	6
Software Turbo Speed.....	7
BIOS Features Setup.....	7
Chipset Features Setup.....	10
Power Management Setup.....	12
PNP/PCI Configuration	16
Load BIOS Defaults	17
Load Setup Defaults.....	17
Integrated Peripherals	17
Supervisor/User Password.....	21
IDE HDD Auto Detection.....	22
Save and Exit Setup	23
Exit without Saving.....	23

This Page Intentionally Left Blank