

To : Users of Manual PA-2006

(Part No. : 25-10580-08)

The mainboards now support AMD-K6 series processors. The corresponding jumper settings are listed as below:

VR1


VR2

2 4 6 8 10
1 3 5 7 9

2 4 6 8
1 3 5 7

Core: 2.9V
IO : 3.3V

**AMD-K6 CPU
Top Side Marking**



V (Identifier for Operation Voltage) :

N 3.1-3.3V Core/3.135-3.6V I/O

L 2.755-3.045V Core/3.135-3.6V I/O

Model Name	CPU Speed	External (CPU/CLK)	CLK1	CLK2	CLK3	CPU Clock Rate		
						Internal	FREQ1	FREQ2
K6-200	200 MHz	66 MHz				3x		
K6-166	166 MHz	66 MHz				2.5x		