

**Kapitel 1      Montage**

Kennwort löschen: CPS .....	2
Flash-EPROM-Wahlschalter: EP1, EP2 .....	2
Externe Taktraten (Bustakt): CLK1, CLK2, CLK3 .....	3
Prozessorfrequenz und Bustakt: FREQ1, FREQ2, FREQ3 .....	3

**Kapitel 2      BIOS-Einrichtung**

Award BIOS-Setup .....	5
CMOS-Einrichtung .....	5
Standard CMOS Setup .....	6
Festplattenkonfiguration .....	6
Software Turbo Speed .....	7
BIOS Features Setup .....	7
Chipset Features Setup .....	10
Power Management Setup .....	12
PNP/PCI Configuration Setup .....	16
Load BIOS Defaults .....	18
Load Setup Defaults .....	18
Integrated Peripherals .....	19
Supervisor/User Password .....	23
IDE HDD Auto Detection .....	23
Save and Exit Setup .....	24
Exit without Saving .....	24

**Diese Seite bleibt absichtlich frei.**