


Instant TV Cardbus



Instant TV Cardbus Drivers

- Before plugging in the **Instant TV Cardbus** into an open cardbus slot of your computer, make sure that the Instant TV Cardbus CD is inserted into your CD ROM drive.
- Windows will attempt to load drivers for the Instant TV Cardbus automatically.
- If the drivers fail to load, the ADS Tech Autorun screen will launch and you can manually click the Driver_Install Button and install the Driver Manually
- Once the Drivers are installed, your PC will need to be restarted.
- Stellen Sie sicher, dass die **Instant TV Cardbus** CD im CD-ROM Laufwerk eingelegt ist, wenn Sie den Computer einschalten.
- Windows wird versuchen, die Treiber für Instant TV Cardbus automatisch zu installieren.
- Wenn die Treiber nicht erfolgreich geladen wurden, dann wird der ADS Tech Autorun Bildschirm angezeigt und Sie können durch Anklicken des Button Driver Install (Treiber Installieren) die Treiber manuell installieren.
- Nach dem Installieren der Treiber muss der PC neu gestartet werden.
- Assurez-vous que le **Instant TV Cardbus** CD est dans le lecteur de CD-ROM quand vous mettez votre ordinateur en marche.

- Windows va tenter de charger les pilotes de Instant TV Cardbus automatiquement.
- Si les pilotes ne chargent pas l'écran « Autorun » d'ADS apparaîtra et vous pouvez manuellement cliquer le bouton*
- Une fois que les pilotes sont installés, votre PC doit être remis en marche.

- Asegúrese que el CD Instant TV Cardbus está en la unidad de CD ROM cuando encienda el ordenador.
- Windows intentará cargar automáticamente los controladores para la tarjeta CardBus Instant TV.
- Si los controladores no se cargan, se EJECUTARÁ la pantalla ADS Tech Autorun y usted puede hacer clic manualmente en el botón Instalar Controladores e instalar el controlador manualmente
- Una vez que se han instalado los controladores, deberá reiniciar el PC.

- Prima di inserire la periferica Instant TV Cardbus in uno slot aperto per cardbus sul computer, verificare che il CD di Instant TV Cardbus si trovi già all'interno del lettore CD-ROM.
- Ora Windows cercherà di caricare automaticamente i drivers per Instant TV Cardbus.
- Se la procedura automatica non dovesse riuscire, il programma lancia ADS Tech Autorun e l'utente potrà cliccare manualmente il pulsante Driver_Install ed installare i drivers.
- Una volta installati i drivers occorrerà riaccendere il computer.

- Voor u de Instant TV CardBus in een vrije CardBus sleuf van uw computer steekt, moet u ervoor zorgen dat de Instant TV CardBus cd in uw cd-romstation zit.
- Windows zal proberen de stuurprogramma's voor de Instant TV CardBus automatisch te laden.
- Als de stuurprogramma's niet worden geladen, zal de ADS Tech wizard geopend worden. Dan kunt u het stuurprogramma manueel laden door een druk op de installatieknop.
- Herstart uw computer zodra de stuurprogramma's zijn geïnstalleerd.

Hardware Installation



Step 1

Locate your Notebook's open Cardbus port and insert the card into the slot.

Finden Sie den Cardbus Steckplatz an Ihrem Notebook und schieben Sie die Karte in den Steckplatz.

Localisez le port Cardbus disponible de votre portable et placez la carte dans la fente.

Localice en su Portátil la puerta Cardbus disponible y enchufe la tarjeta en la puerta

Localizzare la porta Cardbus aperta sul computer portatile ed inserire la scheda.

Zoek de vrije CardBus-sleuf van uw laptop en steek de kaart erin.



Step 2

Push the card all the way into the slot until it is secure.

Schieben Sie die Karte in den Steckplatz ein bis sie festsetzt.

Poussez la carte complètement dans la fente jusqu'à ce qu'elle soit bloqué.

Empuje la tarjeta firmemente en la ranura.

Spingere fino in fondo la scheda nell'apertura, verificandone il completo inserimento.

Duw de kaart helemaal in de sleuf tot hij vast zit.

Service and Warranty

Service:

If you require assistance with the installation, operation, or application of your ADS Technologies, Inc. product the best option available to you is our website at www.adstech.com. Your primary source for information and assistance is always your computer store or computer parts dealer. If your ADS product needs repair or replacement, contact your dealer for on-site repair service.

The ADS Technologies technical support and customer service staff can aid in solving many problems. Our technical support department is available to repair any ADS Technologies product. You or your dealer must return products to our factory for repair or warranty replacement.

Return/Replacement:

If you need to return your ADS Technologies product you should return the product directly to the dealer or store where you purchased the product. Each individual computer store or dealer sets product returns policies for their customers. ADS Technologies, Inc. cannot be responsible for the actions or policies set by our dealers. If you desire to return the product for a refund, you must get the refund from the dealer or store you purchased the product from. If you purchased the product directly from ADS please see the "Terms and Conditions of Sale" on the reverse side of your sales invoice.

Returns to ADS Technologies, Inc. are for repair or warranty replacement only. If you need to return product to ADS Technologies, Inc. for repair or replacement you must follow these steps:

1. Call our Technical Support department at (562) 926-4338 in the USA or +353-61-702042 in Europe to obtain a Return Merchandise Authorization (RMA) number.
2. The RMA number is valid for 30 days.
3. Ship the product to the ADS factory with the RMA number marked on the inside and outside of the package. If there is no RMA number on the package or the RMA number has expired, the shipment will be refused. ADS will not be liable for lost or mis-shipped products.
4. Replacement product cannot be shipped to you until the defective product has been received by ADS.
5. Once the product is received at the factory it will be tested and then repaired or replaced.
6. Turn around time is approximately one week. A repaired or replacement product will be shipped back to you.

Warranty:

This ADS Technologies, Inc. product comes with a One (1) year hardware warranty. ADS Technologies, Inc. (ADS) warrants this product against defects in material and workmanship for a period of One (1) year from the date of original purchase from ADS or an authorized ADS dealer. This warranty applies only to the original purchase of the product and is not transferable. This warranty does not cover any incompatibilities due to the user's computer, hardware, software or other related system configuration in which the product interfaces. Proof of purchase will be required before any warranty consideration by ADS occurs. This warranty does not cover any damage caused by negligence, non-authorized modifications, or parts installed without prior written permission from ADS. This warranty does not apply if the product has been damaged by accident, abuse, or misapplication, nor as a result of service to the product by anyone other than ADS. If your ADS product is not in working order, your only recourse is repair or warranty replacement, as described above. UNDER NO CIRCUMSTANCES will ADS Technologies, Inc. be liable for consequential damages, including but not limited to any lost savings, lost profits, or any other damages, caused by the use of any ADS Technologies, Inc. product or inability to use the product, even if the dealer or ADS Technologies, Inc. has been advised of such liability or other claims. This includes damage to property and, to the extent permitted by law, damages for personal injury. This warranty is in lieu of all other warranties including implied warranties of merchantability and fitness for a particular purpose. **FCC Information**

Federal communications Commission Radio Frequency Interference Statement

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio TV technician for help.

Notice:

- (1) The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- (2) Shielded interface cables and AC power cord, if any, must be used in order comply with the emission limits.