Table of Contents

Chapter 1 Overview

Package Checklist 1-2
KT-400A Pro / KT-400A / KT-600 Pro 1-3
Main Features 1-4
FIC Unique Innovation for Users (NOVUS) -
Enhanced Mainboard Features and System Support 1-6

Chapter 2 Installation Procedures

1). Set System Jumpers 2-2
Clear CMOS 2-2
BIOS Anti-Reflash Protect 2-3
FSB Frequency Select 2-3
2). Install Memory Modules 2-4
3). Install the CPU 2-4
Connect ATX Power 2-6
4). Install Expansion Cards 2-7
5). Connect Devices 2-9
Floppy Diskette Drive Connector 2-9
IDE Device Connectors 2-9
Fan Connectors 2-10
Power Connectors 2-10
Front Panel Block, Power LED, IR, and Speaker Connector 2-10
SPDIF_OUT Connector 2-12
Serial ATA Connectors (KT-600 Pro only) 2-12
CD Audio-In Connectors 2-13
1394 Connectors (optional) 2-13
PS/2 Keyboard and Mouse Connector 2-14
RJ45 LAN Connector 2-14
Serial Port Connectors 2-15
Printer Connector 2-15
Audio I/O Jacks 2-16
Front Audio Connector 2-16
Universal Serial Bus Connectors 2-17

Chapter 3 BIOS Setup

CMOS Setup Utility 3-1
Standard CMOS Setup 3-2
Advanced BIOS Features 3-4
Advanced Chipset Features 3-8
Integrated Peripherals 3-11
Power Management Setup 3-15
PnP/PCI Configurations 3-19
PC Health Status 3-21
Frequency/Voltage Control 3-22
Load Fail-Safe Defaults 3-22
Load Optimized Defaults 3-22
Supervisor/User Password 3-23
Save and Exit Setup 3-23
Exit without Saving 3-23