

Chapter 1 Overview

CW33 Mainboard 1-1
CW33+ Mainboard 1-2
Package Checklist 1-2
The Mainboard 1-3
Main Features 1-4
Intelligent Properties 1-6
ACPI Ready 1-7

Chapter 2 Installation Procedures

1). Set System Jumpers 2-2
Quick Reference 2-3
 Mainboard Layout 2-7
 Password Clearance Function: CLR_PSWD 2-9
 CMOS Clearance Function: CLR_CMOS 2-9
 BIOS Top Block Lock Selection: TBL 2-9
 System Bus Frequency Selection: FS1, FS2 2-10
 Front Panel USB Connector Selection: FNT_USB 2-11
2). Install RAM Modules 2-11
 RAM Module Configuration 2-11
 Install and Remove DIMMs 2-12
3). Install the CPU 2-13
4). Install Expansion Cards 2-14
5). Connect Devices 2-15
 Floppy Diskette Drive Connector: FLOPPY 2-15
 IDE HDD Device Connectors: PRIMARY, SECONDARY .. 2-16
 ATX Power Connector: POWER 2-17
 CPU Fan Connector: CPU_FAN 2-17
 System Case Fan Connector: CHS_FAN 2-17
 Wake-On-Ring Connector: WOR 2-18
 Wake-On-LAN Connector: WOL 2-19
 Infrared Connector: IR 2-19
 CD Audio-Out Connectors: CD_IN1, CD_IN2 2-19
 TV Video Port Connector: RGB_OUT 2-20
 Front Panel Block Connector: F_PNL 2-20
 Video Graphics Accelerator Connector: VGA 2-21
 PS/2 Keyboard and Mouse Connector: KB, MS 2-22

| | |
|---|------|
| Universal Serial Bus Connectors: FNT_USB, Back USBs . | 2-22 |
| Printer Connector: LPT | 2-23 |
| Serial Port Connectors: COM1, COM2 | 2-23 |
| Joystick/MIDI Connector: GAME | 2-24 |
| Audio I/O Jacks: LINE_OUT, LINE_IN, MIC_IN | 2-24 |

Chapter 3 BIOS Setup

Chapter 4 FAQs

| | |
|-----------------------|-----|
| General FAQs | 4-1 |
| BIOS FAQs | 4-5 |
| Windows 98 FAQs | 4-7 |
| Windows 95 FAQs | 4-8 |
| Intel CPU FAQs | 4-9 |