

BIOS Features Setup

ROM PCUIISA BIOS (2A5L7F09)	
BIOS FEATURES SETUP	
AWARD SOFTWARE, INC.	
External Cache	Enabled
Quick Power On Self Test	Disabled
Swap Floppy Drive	Disabled
Boot Up Numlock Status	On
Typematic Rate Setting	Disabled
Typematic Rate (Chars/Sec)	6
Typematic Delay (Msec)	250
Security Option	Setup
Video BIOS Shadow	Enabled
C8000 - C8FFF	Disabled
D0000 - D3FFF	Disabled
D4000 - D7FFF	Disabled
DC000 - DBFFF	Disabled
DD000 - DF7FF	Disabled
ESC: Quit	11 + - : Select Item
F1: Help	PU/PD +/- : Modify
F5: Old Values	(Shift) F2 : Color
F6 : Load BIOS Defaults	
F7 : Load Setup Defaults	

Moving around the BIOS Features Setup program shown above works the same way as moving around the Standard CMOS Setup program.

Users are not encouraged to run the BIOS Features Setup program. Your system should have been fine-tuned before shipment. Improper Setup may cause the system to fail, consult your dealer before making any changes.

External Cache

When enabled, supports an optional cache SRAM.

The available options are: Enabled (Default), Disabled.

Quick Power On Self Test

When disabled, allows the BIOS to bypass the extensive memory test.

The options are: Enabled, Disabled (Default).

Boot Sequence

Allows the system BIOS to first try to boot the operating system from the selected disk drive.

The options are: A, C (Default), C, A.

Swap Floppy Drive

Allows you to switch the order in which the system accesses the floppy drives.

The options are: Enabled, Disabled (Default).

Boot Up Floppy Seek

When enabled, assigns the BIOS to perform floppy disk drive tests by issuing the time-consuming seek commands.

The options are: Enabled (Default), Disabled.

Boot Up Numlock Status

When set to On, allows the BIOS to automatically enable the Num Lock function when the system boots.

The options are: On (Default), Off.

Memory Parity Check

When enabled, allows the DRAM to execute parity bit check.

The options are: Disabled (Default), Enabled.

Typematic Rate Setting

The term "typematic" means that when a keyboard key is held down, the character is repeatedly entered until the key is released. When this item is enabled, you may change the typematic repeat rate.

The options are: Disabled (Default), Enabled.

Typematic Rate (Chars/Sec)

Sets the rate of a character repeat when the key is held down.

The options are: 6 (Default), 8, 10, 12, 15, 20, 24, 30.