

### Jumper Setting for CPU Clock

CPU Speed	External Clock	JK1	JK2	JK3	CPU Clock Rate		
					Int. Multiple	JC2	JC3
133 MHz	66 MHz				2 x Ext.		
120 MHz	60 MHz				2 x Ext.		
100 MHz	66 MHz				1.5 x Ext.		
90 MHz	60 MHz				1.5 x Ext.		
75 MHz	50 MHz				1.5 x Ext.		
<b>Bus / CPU Clock Ratio</b>							
2 : 3							
1 : 2							
1 : 3							
2 : 5							

### Jumper Setting for I/O

J1	Display Type Mono/EGA/VGA CGA
JCP	Password Clear Enabled Disabled (Default)
J1	NS87332/87334 IR serial port (for NS334) COM Port (for NS332) (Default)

### Jumper Setting for System

	CPU Voltage	
	Others	3.3 V 3.5 V (Default)
J15		
J16		
JC1	Internal Write-Back/ Write-Through Cache Write-Back (Default) Write-Through	
JP2	Hardware Reset Enabled Disabled (Default)	
J17	Programmable Flash EPROM Type Intel 28F001BX-T SST 29EE010 (Default)	