



PS/2 Keyboard Connector: PS2_KB


This 5-pin female connector is used for your PS/2 keyboard.

**PS/2 Mouse Connector: PS2_MS**

This 5-pin female connector is used for your PS/2 mouse.

**Remote Power Connector: RPW_CON**

This 3-pin male connector allows you to enable or disable the system power if the RPW_SW is on or off. This allows you to adapt the remote power switch feature. Please contact your dealer for further information.

**Universal Serial Bus Connector: USB1 and USB2 (Reserved For Future Upgrade)**

This connects to the port that allows you to attach a USB hub. The USB connectors are built-in for future upgrade of devices or peripherals that support Universal Serial Bus features.

