


29F040



1. Press the 'Device Selection Button' to select the device type. eg. 29F040
2. Set the DIP switch position 3,5,6,10,11 ON and A18 jumper as above
3. Press the '?' to blank check the chip
4. Load the source file into the Buffer
5. Press the 'Program Button' (the icon with a IC & thunder) to program the chip
6. If the programming is successful, the status bar will shows 'Device program OK'